


---

## **DUAL CLIMA HT EC + EASY CONNECT** **(Outdoor unit + Indoor module)**

**Air/water heat pump**



Thank you for choosing a **DOMUSA TEKNIK** heat pump. From the range of **DOMUSA TEKNIK** products you have chosen the **Dual Clima HT EC** model. With a suitable hydraulic installation, this heat pump will provide the ideal level of comfort for your home.










This document constitutes an essential part of the product and must be delivered to the end user. Read the warnings and recommendations in the manual carefully, as they contain important information on the safety, use and maintenance of the installation.

This heat pump must be installed by qualified personnel only, in accordance with the legislation in force and following the manufacturer's instructions.

Commissioning of this heat pump and any maintenance operations must only be carried out by **DOMUSA TEKNIK's** Authorised Technical Assistance Services.

Incorrect installation of this heat pump could result in damage to people, animals or property, for which the manufacturer will hold no liability.

# CONTENTS

<b>1 SAFETY WARNINGS</b>	<b>5</b>
1.1 USE AND INSTALLATION WARNINGS	5
1.2 PERSONAL SAFETY WARNINGS	5
1.3 TRANSPORT, STORAGE AND HANDLING WARNINGS	6
1.4 FREEZE PROTECTION WARNINGS	6
1.5 HEAT PUMP REFRIGERANT WARNINGS	7
<b>2 ELECTRONIC CONTROL PANEL</b>	<b>8</b>
2.1 CONTROL PANEL	8
2.2 ICONS ON THE CONTROL PANEL	9
2.3 DATE AND TIME SETTINGS	10
<b>3 SWITCHING THE HEAT PUMP ON AND OFF</b>	<b>10</b>
<b>4 OPERATION</b>	<b>11</b>
4.1 SELECTING MANUAL OPERATING MODES	11
4.2 COOLING MODE 	11
4.3 HEATING MODE 	12
4.4 DHW MODE 	12
4.5 COOLING AND DHW MODE  + 	12
4.6 HEATING AND DHW MODE  + 	12
4.7 FUNCTIONING IN HEATING/COOLING "AUTO" MODE	13
4.8 OPERATION WITH ROOM SENSOR	14
4.9 OUTDOOR TEMPERATURE COMPENSATION FUNCTION OTC (OPTIONAL)	15
4.10 OPERATING WITH BUFFER TANK (OPTIONAL)	15
4.11 NIGHT MODE 	17
4.12 ANTI-LEGIONELLA FUNCTION 	17
4.13 SG READY FUNCTION	18
<b>5 TEMPERATURE SELECTION</b>	<b>20</b>
5.1 SETTING THE COOLING MODE SETPOINT TEMPERATURE	20
5.2 SETTING THE HEATING MODE SETPOINT TEMPERATURE	20
5.3 SETTING THE DHW MODE SETPOINT TEMPERATURE	21
5.4 ADJUSTING THE ROOM TEMPERATURE SETPOINT	21
5.5 ADJUSTING THE ANTI-LEGIONELLA FUNCTION SETTINGS	21
5.6 SETTING THE SG READY FUNCTION SETPOINTS	22
<b>6 OUTDOOR UNIT INSTALLATION INSTRUCTIONS</b>	<b>23</b>
6.1 ACCESSORIES SUPPLIED	23
6.2 LOCATION	23
6.3 FIXING THE HEAT PUMP	25
6.4 CONDENSATE DRAINAGE	26
6.5 HYDRAULIC INSTALLATION	26
6.5.1 INSTALLING A DHW TANK	28
6.5.2 INSTALLING A BUFFER TANK	29
6.5.3 FILLING THE INSTALLATION	31
6.5.4 DRAINAGE	31
6.5.5 INSTALLING A DEGASIFIER	32
6.6 OUTDOOR UNIT ELECTRICAL CONNECTIONS	33
6.7 FREEZE PROTECTION	35
6.7.1 DHW MODE ANTI-FREEZE PROCESS	36
6.7.2 HEATING/COOLING MODE ANTI-FREEZE PROCESS	36
<b>7 INDOOR MODULE INSTALLATION INSTRUCTIONS</b>	<b>37</b>
7.1 ACCESSORIES SUPPLIED	37
7.2 LOCATION	37
7.3 CONEXIONES ELÉCTRICAS	38
7.3.1 INDOOR MODULE ELECTRICAL CONNECTIONS	38
7.3.2 CONNECTION TO THE OUTDOOR UNIT	38
7.3.3 CONNECTING THE CONTROL PANEL	39

7.3.4 CONNECTING A DHW SENSOR .....	40
7.3.5 CONNECTING A DHW DIVERTER VALVE (G1) .....	41
7.3.6 CONNECTING A HEATING/COOLING DIVERTER VALVE (G2).....	41
7.3.7 CONNECTING A ROOM SENSOR (OPTIONAL) .....	42
7.3.8 CONNECTING AN OUTDOOR TEMPERATURE SENSOR OTC (OPTIONAL) .....	43
7.3.9 CONNECTING A BUFFER TANK SENSOR (OPTIONAL) .....	43
7.3.10 CONNECTING AN INSTALLATION PUMP C4 (OPTIONAL) .....	44
7.3.11 CONNECTING A ZONE INSTALLATION PUMP Z1 AND/OR Z2 (OPTIONAL) .....	44
7.3.12 CONNECTING A ROOM THERMOSTAT TA1 AND/OR TA2 (OPTIONAL) .....	45
7.3.13 CONNECTING A BACKUP ENERGY SOURCE FOR DHW (E1) .....	45
7.3.14 CONNECTING A BACKUP ENERGY SOURCE FOR HEATING (E2) .....	47
7.3.15 CONNECTING A BACKUP PUMP (C1, C2 AND C3) .....	49
7.3.16 CONNECTING ROOM THERMOSTATS.....	50
7.3.17 CONNECTING SG READY .....	55
7.3.18 CONNECTING A HUMIDITY SWITCH SENSOR (OPTIONAL) .....	55
7.3.19 CONNECTING AN ENERGY METER (OPTIONAL) .....	56
7.3.20 CASCADE INSTALLATION (OPTIONAL) .....	58
8 HEAT PUMP CONFIGURATION .....	60
9 TIME PROGRAMMING.....	61
10 ADDITIONAL FUNCTIONS.....	62
10.1 OPERATION IN CASCADE.....	62
10.2 SOLAR ENERGY UTILISATION FUNCTION .....	64
10.3 INSTALLATION CONDENSATIONS PROTECTION FUNCTION .....	65
11 USER MENU .....	66
12 SETTINGS MENU .....	67
12.1 SYSTEM PARAMETERS.....	67
12.2 OPERATING STATUS.....	69
13 CONFIGURING THE AUXILIARY OR BACKUP ENERGY SOURCES (E1, E2).....	71
13.1 BACKUP SOURCE MODE (P81 = 0).....	72
13.2 AUXILIARY SOURCE MODE (P81 = 1) .....	72
13.3 PASSIVE COMBINED MODE (P81 = 2) .....	72
14 COMMISSIONING.....	73
14.1 PRIOR WARNINGS.....	73
14.2 COMMISSIONING.....	73
14.3 INSTALLATION HANDOVER .....	73
15 MAINTENANCE.....	74
16 RECYCLING AND DISPOSAL .....	74
17 TECHNICAL CHARACTERISTICS .....	75
18 ELECTRICAL DIAGRAMS .....	76
18.1 NOMENCLATURES .....	76
18.2 INDOOR MODULE EASY CONNECT.....	77
18.3 OUTDOOR UNIT DUAL CLIMA 6HT EC, 9HT EC .....	78
18.4 OUTDOOR UNIT DUAL CLIMA 16HT EC.....	79
18.5 OUTDOOR UNIT DUAL CLIMA 12HTT EC, 16HTT EC.....	80
19 DIMENSIONS .....	81
20 CIRCULATION PUMP CHARACTERISTICS .....	82
20.1 CIRCULATION PUMP FLOW CURVES .....	82
20.2 HEAT PUMP PRESSURE DROP.....	83
20.3 CIRCULATION PUMP ADJUSTMENT.....	83
21 PERFORMANCE AND EFFICIENCY CURVES.....	84
21.1 HEATING PERFORMANCE AND EFFICIENCY CURVES.....	84
21.2 COOLING PERFORMANCE AND EFFICIENCY CURVES.....	88
22 ALARM CODES .....	92
23 GUARANTEE CONDITIONS.....	97

## 1 SAFETY WARNINGS

---

### 1.1 Use and installation warnings

The **Dual Clima HT EC** heat pump must be installed by personnel authorised by the Ministry of Industry, in compliance with the applicable laws and regulations. The precautions detailed here cover very important issues. Please be sure to follow them carefully.

Please carefully read this instruction manual and keep it in a safe, easily-accessible place. **DOMUSA TEKNIK** will not be liable for any damages caused by failure to follow these instructions.

The **Dual Clima HT EC** heat pump (outdoor unit) is exclusively suitable to be installed either with communication module Easy Connect (indoor module), or with one of the products of the ranges of indoor units **Fusion HT EC** or **Aqua EC** offered by **DOMUSA TEKNIK**, who integrate the Easy Connect communication module inside.

This heat pump is suitable for use in both heating and cooling installations and can be combined with fan coils, underfloor heating/cooling, low-temperature radiators, and domestic hot water tanks (optional). It must be connected to a heating/air conditioning installation and/or a domestic hot water distribution network and compatible with its performance and power.

This appliance should only be used for the purpose for which it has been expressly designed. Any other use is considered unsuitable and therefore hazardous. The manufacturer shall not be considered liable under any circumstances for damage caused by unsuitable, erroneous or improper use.

Remove all the packaging and check that the contents are complete. In case of doubt, do not use the heat pump and contact your supplier. The packaging components must be kept out of the reach of children, as they constitute potential sources of danger.

Improper installation or placement of equipment or accessories may cause electrocution, short circuit, leakage, fire or other damage to the equipment. Use only accessories or optional equipment manufactured by **DOMUSA TEKNIK** and specifically designed to work with the products in this manual. Do not modify, replace or disconnect any safety or control device without first consulting the manufacturer or the Official Technical Assistance Service of **DOMUSA TEKNIK**.

When you no longer wish to use the heat pump, disable the parts that could represent a potential hazard.

### 1.2 Personal safety warnings

Always wear suitable personal protection equipment (protective gloves, safety glasses, etc.) when carrying out installation and/or maintenance operations in the unit.

Do not touch any switches with wet hands. Touching a switch with wet hands may cause electric shock. Before accessing the electrical components of the heat pump, disconnect the power supply completely.

Disconnect all electricity sources before dismantling the service panel from the electric panel or before making any connections or accessing electrical parts.

To avoid electrocution, ensure the power is turned off for at least 1 minute before servicing the electrical parts. Even after 1 minute has elapsed, always measure the voltage at the terminals of the main circuit capacitors and other electrical parts before touching them, and make sure the voltage is 50 VDC or less.

When the service panels are disassembled, the live parts can be easily accessed. Never leave the unit unattended during installation or during maintenance work when the service panel is removed.

Do not touch the refrigerant pipes, water piping, or internal parts during or immediately after operation. Pipes and internal parts may become very hot or cold, depending on the use of the unit.

The heat or cold could burn your hands if you touch the pipes or internal parts in these conditions. To avoid injury, wait until the pipes and internal parts return to their normal temperature. Alternatively, if you need to access them, be sure to wear appropriate safety gloves.


### 1.3 Transport, storage and handling warnings

The **Dual Clima HT EC** heat pump must be transported, handled and stored in vertical position. Placing the appliance on its side can cause the oil inside the compressor to spill out, causing premature compressor breakage on start-up.

**OK**



**NOT OK**



Do not twist, loosen, or pull the external electric cables of the heat pump. Do not insert any sharp objects through the fan grille or into the fan itself.

Do not clean the interior of the heat pump with water as this may result in electric shock or fire. For any cleaning and/or maintenance operations, disconnect the main power supply.

### 1.4 Freeze protection warnings

The **Dual Clima HT EC** is an appliance for installation on the outside of the building and it will consequently be exposed to frost during periods of extremely cold weather. Frost protection is therefore very important for this type of appliance. If the water inside the heat pump freezes it can cause the pump to break, stopping its functioning and making costly repairs necessary.

It is **compulsory** to use an anti-freeze system in the installation to prevent the water in the units from freezing. **DOMUSA TEKNIK** recommends using anti-freeze liquid in the pump water circuit or an anti-freeze release valve system for draining the installation at very low temperatures. Please read the "Freeze Protection" section in this manual carefully for more detailed information on these systems. **DOMUSA TEKNIK's guarantee does not cover any damage caused by failing to use a freeze protection system.**

The **Dual Clima HT EC** heat pump's electronic control has a function for protecting the water inside it from freezing during periods of frost. **For this function to remain enabled and on standby, the heat pump must be connected to the mains and have a power supply, even when it is switched off or not in use.**

A water filter must be installed in the installation in order to avoid obstructions in the heat pump water circuit. It must be installed on the heat pump's return circuit, and it **MUST** be installed before filling and circulating the water through the installation. The water filter must be checked at least once a year and cleaned if necessary, although in new installations it is recommended to check it a few months after commissioning.

## 1.5 Heat pump refrigerant warnings

The **Dual Clima HT EC** contains **R290** refrigerant gas, which is highly flammable. In normal conditions of use, there is no risk of explosion and the refrigerant is non-toxic. However, in case of leakage, some aspects that could cause damages to third-parties must be taken into account, as the refrigerant could create a flammable atmosphere and give rise to fire or explosion.

All maintenance work must be carried out by qualified staff aware of the dangers of handling refrigerant gases.

**IMPORTANT: The refrigerant gas contained in the heat pump is highly flammable and can cause damage to persons or property.**


The main considerations to be taken into account are as follows:

- The heat pump refrigerant must be recovered for recycling or disposal in accordance with the current legislation.
- In case of leakage, any contact with the refrigerant gas could cause burns. To prevent injury, use the necessary safety protection and avoid contact with the refrigerant gas.
- Leakage could create a flammable atmosphere, giving rise to fire or explosion. As soon as any leakage is detected you must therefore ventilate the area and stay away from the appliance until all the gas has been correctly ventilated.
- The refrigerant must not come into contact with any sparks or sources of ignition. Refrigerant leaks must be detected using suitable devices for R290 refrigerant gas.
- It is **compulsory** to use a safety system in the installation for the case of refrigerant leaks. **DOMUSA TEKNIK** advises installing a degasifier in the pump water circuit. Please read the section "*Installing a degasifier*" in this manual carefully for more detailed information on this system. **DOMUSA TEKNIK will not be liable for any damages caused by failing to have a safety system in place for refrigerant leakage.**
- The heat pump must be installed by qualified personnel and in compliance with all current regulations.

## 2 ELECTRONIC CONTROL PANEL

### 2.1 Control panel

The electronic control unit of the **Dual Clima HT EC** heat pump has a touchscreen for controlling all the adjustable functions and settings.



#### 1. Temperature selection:

Press this button to change the temperature for the different operating modes.

#### 2. Status indicator:

Display of heat pump running status indicator icons every moment.  
(See "Icons on the control unit").

#### 3. DHW setpoint temperature:

This selects and displays the DHW setpoint temperature. (See "Temperature selection").

#### 4. Heating setpoint temperature:

This selects and displays the heating setpoint temperature. (See "Temperature selection").

#### 5. Room temperature setpoint:

This selects and displays the room temperature setpoint in the inside the local.  
(See "Temperature selection").

#### 6. Cooling setpoint temperature:

This selects and displays the cooling setpoint temperature. (See "Temperature selection").

#### 7. Programming Menu touch button:

Press this button to access the heat pump programming menu.  
(See "Time programming").

#### 8. User Menu touch button:

Press this button to access the heat pump user menu. (See "User Menu").

#### 9. Settings Menu touch button:

Press this button to access the heat pump configuration menu. (See "Settings Menu").

#### 10. Operating Mode Menu touch button:

Press this button to access the different operating modes.  
(See "Selecting the operating modes").



### 11. On/Off button:

This button switches the heat pump on and off.

### 12. "+" touch button:

Press this button to increase the setpoint temperature for the different operating modes.

### 13. "-" touch button:






















Press this button to reduce the setpoint temperature for the different operating modes.

### 14. Date and time:

This selects and displays the date and time.

## 2.2 Icons on the control panel


The display has different display areas and sets of icons and numbers indicating the different statuses of the heat pump.

Operating modes:	
	OTC mode enabled.
	Cooling Mode enabled.
	Heating Mode enabled.
	DHW Mode enabled.
	Buffer cooling mode enabled.
	Buffer heating mode enabled.
	Operation with a room temperature sensor enabled.
Additional functions:	
	External temperature indicator.
	Photovoltaic function enabled.
	Humidity function enabled.
	Antifreeze Function enabled.
	Defrost Function activated.
	Anti-legionella Function enabled.
	Time programming activated.
	Night mode enabled.
	SG Ready function enabled in On mode.
	SG Ready function enabled in Off mode.
	Heat pump alarm indicator.
	Compressor indicator enabled.
	Cascade function enabled.
	Active operation mode indicator in every moment.

## 2.3 Date and time settings

The **Dual Clima HT EC** heat pump has a date and time indicator (14), for managing some of its functions. It is therefore vital to set the correct date and time on starting up the heat pump.


Press on the time indicator on the start screen to accede to time and date setup screen.



**NOTE:** An incorrect date and time setting may cause some features to malfunction.

## 3 SWITCHING THE HEAT PUMP ON AND OFF

To switch on the heat pump, press the On button (11) for 5 seconds. The heat pump will switch on in the last previously selected operating mode and the On button will light up in red. Different operating mode icons will light up on the digital display depending on the operating mode selected.




To switch off the heat pump, press the Off button (11) hold it down for 5 seconds. The heat pump will run through its switch-off sequence.

## 4 OPERATION

### 4.1 Selecting manual operating modes

Depending on the configuration of your installation, the **Dual Clima HT EC** heat pump can manage up to 5 operating modes manually. To select these operating modes, press the Operating modes touch button **M** (10) on the start screen. The following modes will appear on the display:



The selectable operating modes are as follows:

- Heating Mode.
- Cooling Mode.
- Domestic Hot Water (DHW) Mode.
- + Heating and DHW mode
- + Cooling and DHW mode

When the heat pump is configured and installed for "AUTO" mode functioning, the Heating and Cooling modes cannot be selected manually, as the heat pump will enable and disable them via a signal from the remote room thermostat connected to it (see "*Functioning in Heating/Cooling "AUTO" mode*").



In case that a buffer tank is enabled, the heating and cooling icons will be replaced by their homologues et respectively (see "*Operation with buffer tank*").

Depending on the configuration of your installation, some of the operating modes listed may not be selectable. Please read the following sections carefully as they describe the functioning of these modes in detail.

### 4.2 Cooling mode

This mode can only be selected if the heating/cooling installation is designed to function in Cooling mode (underfloor cooling, fan coils, etc.) and the heat pump is configured accordingly.



In this operating mode, the **Dual Clima HT EC** heat pump will cool the water in the heating/cooling installation and maintain it at the desired temperature. To do this, select the desired cooling setpoint temperature (see "*Temperature selection*") and the room thermostat temperature (if the unit has a thermostat) (see "*Functioning in Heating/Cooling "AUTO" mode*") or the room sensor temperature if the room sensor function is enabled (see "*Operation with room sensor*").

In case that a buffer tank is enabled, the cooling icon  will be replaced by the homologue , (see *"Operation with buffer tank"*) and the heating pump will cool the water in the buffer tank to the selected setpoint temperature.

This mode will **only** affect the heating/cooling installation, and if the unit has DHW production it will be disabled.

### 4.3 Heating mode

In this operating mode, the **Dual Clima HT EC** heat pump will heat the water in the heating/cooling installation and maintain it at the desired temperature. To do this, select the desired heating setpoint temperature (see *"Temperature selection"*) and the room thermostat temperature (if the unit has a thermostat) (see *"Functioning in Heating/Cooling "AUTO" mode"*) or the room sensor temperature if the room sensor function is enabled (see *"Operation with room sensor"*).

In case that a buffer tank is enabled, the heating icon  will be replaced by the homologue , (see *"Operation with buffer tank"*) and the heating pump will heat the water in the buffer tank to the selected setpoint temperature.

This mode will **only** affect the heating/cooling installation, and if the unit has DHW production it will be disabled.

### 4.4 DHW mode

This mode will only be selectable if the installation has a Domestic Hot Water storage tank connected and the heat pump is configured accordingly.



In this operating mode, the **Dual Clima HT EC** heat pump will heat the water in the domestic hot water storage tank to the desired temperature, to provide DHW to the home. To do this, select the desired DHW setpoint temperature (see *"Temperature Selection"*). When the desired temperature is reached the heat pump will stop and will remain on standby until it receives a DHW request.

This mode will **only** affect the DHW storage tank installation, and the heating and/or cooling function of the heating/cooling installation will be disabled.

### 4.5 Cooling and DHW mode +

This mode will only be selectable only if the heating/air conditioning system is designed to operate in Cooling mode (underfloor cooling system, fan coils, etc.); the installation has a connected domestic hot water storage tank and the heat pump is configured accordingly.

This operating mode is the combination of the Cooling and DHW simultaneously. When a DHW request is activated, the heat pump will disable Cooling mode and enable Domestic Hot Water mode, giving priority to DHW production over the cooling function of the heating/air conditioning installation. Once the desired DHW temperature is reached, the heat pump will enable Cooling mode again.

In case that a buffer tank is enabled, the cooling icon  will be replaced by the homologue , (see *"Operation with buffer tank"*).

### 4.6 Heating and DHW mode +

This mode will only be selectable if the installation has a Domestic Hot Water storage tank connected and the heat pump is configured accordingly.

This operating mode is a simultaneous combination of the Heating and DHW modes. When a DHW request is activated, the heat pump will disable Heating mode and enable Domestic Hot Water mode, giving priority to DHW production over the heating function of the heating/air conditioning installation. Once the desired DHW temperature is reached, the heat pump will enable Heating mode again.

In case that a buffer tank is enabled, the heating icon ☀️ will be replaced by the homologue 🚿, (see *"Operation with buffer tank"*).

## 4.7 Functioning in Heating/Cooling "AUTO" mode


In **"AUTO"** mode, the **Dual Clima HT EC** heat pump can enable Heating or Cooling mode "automatically". To enable this operating mode, the electronic control has 2 connections (one for enabling Heating mode and the other for enabling Cooling mode). A **heating/cooling switching (3-wire) room thermostat** can be connected so that the heat pump will enable one of the two operating modes automatically and remotely from wherever this room thermostat is located in the home. To correctly install this thermostat, carefully follow the instructions provided in the section *"Connecting a Room Thermostat"*.

Operation with a room thermostat will not affect DHW production (if the unit is equipped with this), which will continued to be enabled regardless of the status of the thermostat.







The installation of a room thermostat will optimise the installation's performance, adapting the heating and/or air conditioning to the requirements of your home and obtaining enhanced comfort. Additionally, if the thermostat allows the operating hours to be programmed (chronothermostat), it can adapt the system to the hours of use of the installation.

When a hot/cold room thermostat or chronothermostat has been connected, the heat pump will automatically enable Heating or Cooling operating mode according to the selection made on the thermostat and depending on the temperature inside the home. When DHW production is selected on the heat pump control panel ( 🚿 ), the electronic control will enable Heating and Cooling modes in combined DHW production mode, as described in the sections *"Cooling and DHW Mode" ❄️ + 🚿* and *"Heating and DHW Mode" ☀️ + 🚿*, so that the automatic selection of an operating mode will not affect DHW production.

Once the thermostat has been installed in the home, select the desired temperature, the operating mode (Heating or Cooling) and the operating times, if it is a chronothermostat (see the Thermostat Manual). The heat pump will switch on and enable the operating mode selected on the thermostat (Heating or Cooling), until the set temperature is reached. When the desired temperature is reached in the home, the heating or cooling function of the heating/air conditioning installation will be disabled, turning off the operation of the heat pump. The information shown below will appear on the electronic control panel to indicate that the heat pump has been switched off by the room thermostat (standby).



The table below shows the functioning of the **Dual Clima HT EC** heat pump in **"AUTO"**, mode, depending on the remote mode selection made on the Hot/Cold thermostat:

Thermostat Selection	Dual Clima HT EC	Control panel
Heating	Heating Mode: The heat pump enables Heating mode.	
	Combined Heating + DHW mode: The heat pump enables Heating mode, providing the desired setpoint temperature has already been reached in the DHW storage tank.	
Cooling	Cooling Mode: The heat pump enables Cooling mode.	
	Combined Cooling + DHW mode: The heat pump enables Cooling mode, providing the desired setpoint temperature has already been reached in the DHW storage tank	
OFF (Stand By)	Heating or Cooling Modes: When the desired temperature is reached in the home, or when the room thermostat is disabled (if it equipped with this function), the heating or cooling function will be disabled.	
	Combined Heating or Cooling + DHW modes: When the desired temperature is reached in the home, or when the room thermostat is disabled (if it equipped with this function), the heating or cooling function will be disabled and DHW mode will remain enabled.	

#### 4.8 Operation with room sensor

This operating mode cannot be enabled until a room temperature sensor is connected to the **Easy Connect** indoor module (see *"Connecting the room sensor"*). To enable this function, set parameter **P116** of the "System Parameters" menu to **1** (see *"Settings Menu"*). Also, parameters **117** (in Heating mode) and **118** (in Cooling mode) can be used to set the difference in temperature needed to reactivate demand after reaching the desired temperature. The range of temperatures that can be selected is 0.2~5°C. The default factory setting is 0.5°C.

Operation with the room temperature sensor will optimise the Heating/Cooling installation by adapting the operation of the heat pump to the needs of the home and achieving a higher degree of comfort. The electronic control unit will adjust the temperature setpoints of the heat pump according to the room conditions registered by the room temperature sensor installed in the home. This will optimise fuel savings and increase installation efficiency.

This feature applies to both operating modes of the heat pump; both Heating and Cooling. To initiate operation, select the corresponding operating mode, Heating or Cooling (see sections above), the temperature setpoint for the selected mode and the room temperature setpoint for the home (see *"Selecting temperatures"*).

Once operation with the room temperature sensor is enabled, activate the time programming of the room temperature setpoint by setting parameter **P138** of the "System Parameters" menu to **1** (see *"Settings Menu"*). This option is used to adjust room temperature setpoints as needed for each programming period (see *"Time programming"*).




## 4.9 Outdoor temperature compensation function OTC (Optional)

This operating mode cannot be enabled until an outdoor OTC sensor is connected to the **Easy Connect** indoor module (see *"Connecting an outdoor temperature sensor OTC"*). To enable this function, set parameter **P120** of the "System Parameters" menu to any value other than **OFF** (see *"Settings Menu"*). The home screen of the control panel will show the **"OTC"** acronym, which will replace the Heating setpoint.

When this operating mode is enabled, the Heating temperature of the heat pump or the buffer tank, if there is one, will be calculated according to the slope of the K curve selected in parameter **P120** and the outdoor temperature measured by the outdoor temperature sensor. If the installation is the proper size, the temperature of the heat pump calculated by this function will ensure a room temperature that corresponds to the programmed setpoint.

The slope of the K curve reflects the association between the outdoor temperature and the Heating temperature setpoint of the heat pump or buffer tank, if there is one. The attached chart shows the list of temperatures for each K curve value.



The ideal K curve will vary according to the type of heating circuit, the insulation conditions of the building and the location of the outdoor temperature sensor. As a general rule, a K curve of 1 or higher is recommended for high temperature heating circuits (e.g., a direct circuit of "radiators"), whereas a K curve of 0.8 or lower is recommended for low temperature circuits (e.g., a combined "underfloor heating" circuit). In the latter type of circuit, it is not recommended to select a K curve that can generate temperatures over 55°C, since this can damage the installation and the furniture in the home.

**The DOMUSA TEKNIK warranty does not cover damage caused by selecting an inappropriate K curve for operation.**

**NOTE: Inappropriate selection of the K curve may result in the heating installation not generating the desired conditions in the home, not heating enough in extremely cold weather or heating too much in warm weather conditions.**

## 4.10 Operating with buffer tank (Optional)

The **Dual Clima HT EC** heat pump can be installed in conjunction with a **Buffer tank** (BT, BT-Duo, Fusion Trio, etc.) from the wide range of air source accessories made by **DOMUSA TEKNIK**. This tank stores thermal energy to improve the performance of the installation when the heat pump switches on or off. For proper installation, carefully follow the assembly instructions provided with the tank; in addition, to connect it to the heat pump, read the instructions provided in the *"Installing a buffer tank"* section of this manual.

This operating mode cannot be enabled until a room temperature sensor is installed in the buffer tank and connected to the **Easy Connect** indoor module (see *"Connecting the buffer tank sensor"*). To enable this function, set parameter **P121** of the "System Parameters" menu to **1** (see *"Settings Menu"*). On the home screen of the control panel, the ☀️ (Heating mode) and ❄️ (Cooling mode) icons will be replaced by their corresponding 🛀 and 🧊 icons, respectively. In turn, parameter **122** can be used to set the difference in temperature needed to reactivate tank water heating or cooling after the desired temperature is reached. The range of temperatures that can be selected is 5~40°C. The default factory setting is 5°C.

In this operating mode, users must select the desired temperature setpoint for the buffer tank (see *"Selecting temperatures"*), the Heating or Cooling operating mode and the temperature setpoint of the installed thermostat or room temperature sensor. Depending on the temperature read by the tank sensor and the status of the room thermostats and/or sensors in the installation, the electronic control unit of the **Easy Connect** indoor module will switch on the heat pump to reach the temperature setpoint of the buffer tank at any given time. When the temperature in the tank reaches the selected setpoint, the heat pump will switch off until the temperature drops (Heating mode) or rises (Cooling mode) below or above the desired temperature by the amount set in parameter **P122** (5°C by default), which will start a new heating or cooling cycle.

When this operating mode is enabled, apart from managing the buffer tank temperature, the **Easy Connect** indoor module can also manage the hydraulic heating and cooling circuits installed downstream from the tank, provided the installation is configured for this purpose (see *"Installing a buffer tank"*). Operation would be as follows, depending on the configuration of the installation:

### **Installation with Room Temperature Sensor**

This type of installation requires selecting the buffer tank setpoint, the heat pump operating mode and the room temperature setpoint (see *"Selecting temperatures"*). The electronic control unit will manage the operation of the **C4** circulation pump, depending on the temperature registered by the room sensor installed inside the home and the adjusted setpoint (see *"Operation with room sensor"*).

### **Installation with room thermostats TA1 and/or TA2**

This type of installation requires selecting the buffer tank setpoint, the heat pump operating mode and the room temperature setpoints of thermostats **TA1** and/or **TA2** installed inside the home. Moreover, **the operation of both thermostats must be set according to the selected operating mode, Heating or Cooling**. The electronic control unit will use the signal received at inputs **TA1** and/or **TA2** of the indoor module to activate or deactivate operation of circulation pumps **Z1** and/or **Z2**, respectively. These pumps will be used to manage heating or cooling of up to 2 separate Heating/Cooling zones.

### **Operation with 2 room thermostats**

If two thermostats are used simultaneously (one for Heating and one for Cooling) (see *"Connecting a Room Thermostat"*), when they have been installed select the desired temperatures and the operating times if a chronothermostat is used (see the Thermostat Manual). The heat pump will switch on and enable the operating mode for which the thermostat has been installed (Heating or Cooling), until the temperature set on the room thermostat is reached. When the desired temperature is reached in the home, the heating or cooling function of the heating/air conditioning installation will be disabled, turning off the operation of the heat pump. The information shown below will appear on the electronic control panel to indicate that the heat pump has been switched off by the room thermostat (standby).



**IMPORTANT:** Ensure the correct temperatures are selected on each one to prevent crossover, with both thermostats being enabled at the same time.



## **Operation with the heating/cooling switching (2-wire) thermostat**

If a **heating/cooling switching (2-wire) room thermostat** is installed, the same operating mode (Heating or Cooling) will need to be selected on the heat pump as the mode it is to work in. Once the thermostat is installed in the home, select the desired temperature and operating times, if it is a chronothermostat (see the Thermostat Manual). The heat pump will switch on and activate the selected operating mode (Heating or Cooling) until the temperature set on the room thermostat is reached. When the desired temperature is reached in the home, the heating or cooling function of the heating/air conditioning installation will be disabled, turning off the operation of the heat pump. The information shown below will appear on the electronic control panel to indicate that the heat pump has been switched off by the room thermostat (standby).



**IMPORTANT:** ensure the operating mode is correctly selected on the heat pump, so that both of them work in the same mode.

### **4.11 Night Mode** ☾

In order to reduce the number of switch-ons and noise caused at antisocial times (at night), the **Dual Clima HT EC** heat pump can be activated in Night Mode. On operating in Night Mode, in DHW mode the setpoint temperature that has been set will automatically be increased by 3°C, in Heating mode it will automatically be reduced by 2°C, and in Cooling mode it will automatically be increased by 2°C.

To enable and configure this operating mode, you must adjust parameters **P15**, **P16** and **P17** in the System Parameters (see *Settings Menu*). By default, the heat pump is supplied with Night Mode disabled. To enable it, set parameter **P17** to 1. Also, parameter **P15** is used to select Night Mode start time and parameter **P16** to select Night Mode end time. The default times are from 10.00 p.m. to 6.00 a.m.

### **4.12 Anti-legionella function** ⛶

This function prevents the proliferation of Legionella bacteria in the domestic hot water accumulated in the tank, so it will only be available if the installation has a connected Domestic Hot Water storage tank and the heat pump is configured accordingly.

To enable this function, adjust parameter **P14** in the System Parameters (see *Settings Menu*). The heat pump has the anti-legionella function disabled by default. To enable it, set parameter **P14** to **0**.

The function will regularly increase the temperature of the domestic hot water in the tank to 50~70 °C. The desired temperature and frequency can be selected for this purpose (see *"Temperature selection"*). This function will be activated regardless of the operating modes that enabled at the time of commissioning, even when the heat pump is in standby mode.

Also, providing the function is enabled (**P14=0**), this function can be activated manually at any time using the parameter **P14** in the System Parameters (see *Settings Menu*). Setting parameter **P14** to **1** will enable the anti-legionella function once. When the function is activated it cannot be stopped and you must wait until the cycle is complete for the appliance to resume its normal functioning.

### 4.13 SG Ready function

The **Dual Clima HT EC** heat pump includes the **SG Ready** (Smart Grid) function. This function allows the power company to communicate with the heat pump and adapt it optimally to the mains network demand via a smart control. Its consumption can therefore be adapted to the grid requirements, helping accumulate energy at the most profitable times and avoiding consumption when the grid demand is highest.








By default, the heat pump is supplied with the SG Ready function disabled. To activate it, set parameter **P201** to 1. Also, to accumulate energy at the times determined by the power company and to adapt your consumption to grid demand, new heating, cooling and/or domestic hot water setpoints will need to be selected for each operating mode.

**NOTE: To ensure energy storage with the SG Ready function, it is necessary to have a DHW storage tank and buffer tank for heating and/or cooling installed.**

This function will accumulate energy and


This function will accumulate energy and reach the newly defined setpoints using both the compressor and the back-up energy sources for DHW (E1) and heating (E2). To set the working mode of the heat pump to SG Ready, adjust parameter **P208** of the System Parameters (see "*Settings Menu*") to operate with heat pump and backup energy sources for DHW (E1) and heating (E2), or operating only with heat pump, or finally, operating only with backup energy sources E1 and E2. If only the heat pump is to be worked with, bear in mind that the backup energy sources for DHW (E1) and heating (E2) will not work to reach the newly defined setpoints, regardless of the auxiliary or backup energy sources (**P81**) selected.

The **Easy Connect** communication indoor module incorporates two terminal strip inputs **X1** (see "*Connection Diagram*"). In combination with the different options, these inputs define 4 **SG Ready** operating modes:

	MODE OFF	MODE STANDARD	RECOMMENDED START-UP MODE	MODE ON
<b>SG1</b>	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
<b>SG2</b>	OFF (Open)	OFF (Open)	ON (Closed)	ON (Closed)
<b>CONNECTION DIAGRAM</b>				
<b>REMOTE CONTROL</b>		-		

### **Off mode**

In off mode, when there is an excessive power consumption demand in the grid, the power company instructs the heat pump not to switch on at all (standby mode). The heat pump will not switch on in heating, cooling and/or domestic hot water mode. None of the safety functions (anti-freeze, defrost, etc.) will be affected in this operating mode. Off mode will last for a **maximum of 2 hours**.

While off mode is operational, the **SG Ready** Function icon will be displayed in off mode  on the start screen, indicating that **SG Ready** function has turned off the heat pump operation.


### **Standard mode**

In standard mode, the power company cannot alter the functioning of the heat pump. The heat pump will operate normally and no icon will be displayed on the start screen.

### **Recommended start-up mode**

In recommended start-up mode, the power company recommends switching on the heat pump in order to adapt consumption to the mains demand. This will require the selection of new heating, cooling and/or domestic hot water setpoints depending on the installation. The new setpoints must be selected by technically qualified personnel. To do this, parameters **P202**, **P204** and **P206** of the System Parameters must be adjusted (see *Settings Menu*).

While recommended start-up mode is enabled, the function will increase the temperature in the DHW tank and/or buffer tank installed to the selected temperature.


While recommended start-up mode is operational, the **SG Ready** Function icon will be displayed in on mode  on the start screen, indicating that **SG Ready** function has turned on the heat pump operation with new setpoint temperatures.

**NOTE: Incorrect setting of the parameters may result in the heating system not providing the desired comfort in the house.**

### **Start-up mode**

In start-up mode, the power company forces heat pump switch-on in order to adapt the consumption to the grid demand. This will require the selection of new heating, cooling and/or domestic hot water setpoints depending on the installation. The new setpoints must be selected by technically qualified personnel. To do this, parameters **P203**, **P205** and **P207** of the System Parameters must be adjusted (see *Settings Menu*).


While start-up mode is enabled, the function will increase the temperature in the DHW tank and/or buffer tank installed to the selected temperature.

While start-up mode is operational, the **SG Ready** Function icon will be displayed in on mode  on the start screen, indicating that **SG Ready** function has turned on the heat pump operation with new setpoint temperatures.




**NOTE: Incorrect setting of the parameters may result in the heating system not providing the desired comfort in the house.**

## 5 TEMPERATURE SELECTION

The desired setpoint temperatures for each operating mode can be set using the digital display. To access them, select the operating mode you wish to display or change using buttons (3), (4), (5) or (6) and select the required temperature using buttons (1), (12) or (13). The selected temperature will be displayed in the centre of the screen.






### 5.1 Setting the Cooling Mode setpoint temperature

Press  button to select the setpoint temperature desired for Cooling mode. The selectable range of values for Cooling operating mode is 7~25 °C. The pre-set default value is 12°C. In case of a buffer tank is enabled, selected setpoint temperature will be applied to the water in the buffer tank. In case that a buffer tank is enabled, the cooling icon  will be replaced by the homologue , (see "Operation with buffer tank").

To correctly set suitable values for this operating mode, follow the recommendations given by the installer or the **DOMUSA TEKNIK** Official Technical Service. Depending on the type of installation, the location (climatic zone) and the relative humidity of the home, excessively low temperatures of the Cooling mode setpoint may create "undesired" condensation in the heating/air conditioning system, causing deterioration and damage in the home.

**IMPORTANT:** **DOMUSA TEKNIK** will not be held liable for any damages and/or breakdowns in either the installation or the home caused by inadequate selection of the Cooling Mode setpoint temperature.

### 5.2 Setting the Heating Mode setpoint temperature

Press  button to select the setpoint temperature desired for Heating mode. The selectable range of values for Heating operating mode is 10~75 °C. The pre-set default value is 45°C. In case of a buffer tank is enabled, selected setpoint temperature will be applied to the water in the buffer tank. In case that a buffer tank is enabled, the heating icon  will be replaced by the homologue , (see "Operation with buffer tank").


To correctly set suitable values for this operating mode, follow the recommendations given by the installer or the **DOMUSA TEKNIK** Official Technical Service. Depending on the type of installation (radiating floor,...), excessively high temperatures of the Heating mode setpoint may cause deterioration and damage both in the installation or in the house.

**IMPORTANT: DOMUSA TEKNIK will not be held liable for any damages and/or breakdowns in either the installation or the home caused by inadequate selection of the Heating Mode setpoint temperature.**

In case of outdoor temperature compensation (OTC) function is enabled, the start screen will display **OTC** and the setting of setpoint temperature will be calculated automatically by the electronic control, depending on external temperature measured outside the local and the curve selected by the installer or the Official Technical Assistance Service (see "*Functioning according to outdoor temperature conditions*").


**NOTE: If automatic operating according to the outdoor temperature conditions ("OTC") is selected, incorrectly setting the operating curves could mean the heating installation may not generate the desired thermal comfort in the home, as it will provide insufficient heat when the outdoor temperature is extremely cold and/or excessive heat in hot weather.**

### 5.3 Setting the DHW Mode setpoint temperature

Press  button to select the setpoint temperature desired for DHW mode. The selectable range of values for DHW operating mode is 10~70 °C. The pre-set default value is 45°C.

If the desired temperature in the tank is higher than the value selected for parameter **P35** of the System Parameters (see "*Settings Menu*"), an auxiliary heat source must be installed on the tank as a backup (electric heating element, backup boiler, etc.). The **Dual Clima HT EC** heat pump will heat up the water in the tank to the value selected for parameter **P35**. After this, it will activate the auxiliary heat source **E1** to reach the highest desired temperature. The selectable range of values for **P35** parameter is 10~70 °C. The pre-set default value is 70°C.

### 5.4 Adjusting the Room temperature setpoint

In case there is enabled operation with room sensor, the room temperature touch button  is displayed in the start screen. Press this button to select the desired room temperature setpoint. The selectable range of values for room temperature is 18~35 °C. The pre-set default value is 21°C.

### 5.5 Adjusting the Anti-Legionella function settings

To set and activate the anti-legionella function, you must adjust parameters **P10**, **P11**, **P12** **P13** and **P14** of the System Parameters (see "*Settings Menu*").

#### Activating the Anti-legionella function

To activate the anti-legionella function, you must adjust parameter **P14** of the System Parameters (see Settings Menu). The selectable range of values is 0~2.

- **P14=0:** Automatic operation of anti-legionella function.
- **P14=1:** Manual operation of anti-legionella function. The anti-legionella function will be activated once when manual mode is selected. The function will not be run again until its next manual enablement.
- **P14=2:** Anti-legionella function switch-off.

#### Anti-Legionella Temperature

To select the anti-legionella setpoint temperature, you must adjust parameter **P13** of the System Parameters (see "*Settings Menu*"). The selectable range of values for the anti-legionella function is 50~70 °C. The pre-set default value is 70°C.

## **Frequency**

To adjust the activation frequency of the anti-legionella function (in days), you must adjust parameter **P10** of the System Parameters (see *Settings Menu*). The selectable range of values is 1~99 days. The pre-set default value is 7 days.

## **Start Time**

To adjust the time at which the anti-legionella function is activated, you must adjust parameter **P11** of the System Parameters (see *Settings Menu*). The selectable range of values is 0-23 hours. The pre-set default value is 23 hours (23.00h).

## **Maintenance minutes**

To adjust the length of time the function will remain active once the selected temperature has been reached, you must adjust parameter **P12** of the System Parameters (see *Settings Menu*). The selectable range of values is 5~99 minutes. The pre-set default value is 10.

## **5.6 Setting the SG Ready function setpoints**

For configuring and operating the SG Ready function, in "Recommended Start-up" and "On" modes, new for heating, cooling and/or domestic hot water setpoints need to be selected for each operating mode. See "*SG Ready function*".

To select new heating setpoints, parameters **P202**, for Recommended start-up mode, and **P203**, for On mode, must be adjusted. The selectable range of values is 0~75 °C. The preset default value for both is **OFF**. If the **OFF** default value is kept, no new temperature setpoints will be applied for the operating modes.

To select new cooling setpoints, parameters **P204**, for Recommended start-up mode, and **P205**, for Start-up mode, must be selected. The selectable range of values is 10~30 °C. The pre-set default value for both is **OFF**. If the **OFF** default value is kept, no new temperature setpoints will be applied for the operating modes.

To select new domestic hot water setpoints, parameters **P206**, for Recommended start-up mode, and **P207**, for On mode, must be adjusted. The selectable range of values is 0~70 °C. The pre-set default value for both is **OFF**. If the **OFF** default value is kept, no new temperature setpoints will be applied for the operating modes.

**NOTE: Incorrect setting of the parameters could mean the heating installation may not generate the desired thermal comfort in the home.**




## 6 OUTDOOR UNIT INSTALLATION INSTRUCTIONS

### 6.1 Accessories Supplied

The following accessories are supplied inside the **Dual Clima HT EC** heat pump. Before installing the appliance, make sure none of these accessories are missing or damaged.




**Documentation:** You will find the documentation bag inside the appliance, opening the front panel. It includes all the necessary manuals and documents for using and installing the heat pump.



**Control panel:** You will find the control panel inside the appliance, on removing the electronic card cover. The control panel must be installed inside the home before connecting the power supply to the appliance.



**Blow-off valve:** This is supplied inside the appliance, fastened with a cable tie to one of the compressor feet. The valve must be fitted to the drain socket on the rear of the heat pump before filling the heating/air conditioning circuit with water (see "*Diagrams and measurements*").



**4x Anti-vibration supports:** Four supports are supplied in a bag taped to the rear of the appliance, beside the hydraulic connections.



**Condensate drain valve:** This is supplied inside the appliance, fastened with a cable tie to one of the compressor feet. This valve must be fitted to the condensate drain socket at the bottom of the rear side of the heat pump.




**DHW temperature sensor:** This is supplied inside the appliance, inside the documentation bag. This sensor is used for installing a DHW tank. For a correct installation read "*Indoor module installation instructions*".

### 6.2 Location


The heat pump (outdoor unit) must be installed exclusively outside the home and, where possible, in an area free from obstructions. If a guard around the appliance is required, it must have spacious openings on all four sides, leaving the minimum required spaces for installation as indicated in the figure below. There must be no obstacles preventing air circulation through the evaporator and at the fan outlet.

Consult the user before choosing the location of the appliance. Do not install it beside walls where it could create noise problems, e.g. a wall next to a bedroom. Make sure that the location of the heat pump is not disruptive to neighbours (noise level, draughts, cold air outlet creating risk of freezing for plants in its path, etc.).


A location with sunlight and protected from strong cold winds (mistral, tramontane, etc.) is preferable. If the heat pump is exposed to gusts of wind that could overturn it, it should be supported by suitable anchoring devices, as shown in the figure.



The device must be sufficiently accessible for subsequent installation and maintenance work. Ensure that there is sufficient room available to make the hydraulic and electrical connections into the home. The separation measurements shown in the figure above are those strictly necessary to ensure correct operation of the appliance. However, it will sometimes be essential to provide more space for maintenance work.



Minimum separations for installation of a unit (mm).



Minimum separations for installation of multiple units in the same location (mm).

The **Dual Clima HT EC** heat pump is an appliance specially designed for outdoor installation, but it should not be installed in locations where it could be exposed to major water spills or splashes (below a damaged gutter, near a gas outlet, etc.). Keep the appliance away from heat sources and flammable products.




In areas where heavy snowfall occurs, special care must be taken to protect the heat pump from any obstruction around it due to snow accumulation. The obstruction of the appliance's air inlet and/or outlet by snowdrifts could malfunctioning of the unit and possible breakdowns. The heat pump must be installed at least 100 millimetres above the maximum expected snow level. The roof must also be protected from snow accumulation by a roof overhang on the building or a similar structure.

In addition, for the installation of the heat pump, all current regulations and restrictions must be considered. Among others, considering the flammability of the refrigerant gas, heat pumps must respect the safety distances detailed in the following table:

Element	Minimum distance (m)
Possible sources of ignition	1,5
Electrical switches and plugs	0,5
Electric conductors	0,3
Combustion engines	1,5
Registration of sewers, drains, etc.	1,5
Basement openings	1,5

### 6.3 Fixing the Heat Pump

The heat pump should be firmly fixed to a base, preferably a concrete base. Fix it firmly using 4 sets of M12 bolts suitable for the base material, with nuts and washers (available on the market). Make sure that the protruding distance of the bolt inside the metallic support of the appliance (leg) does not exceed 10 mm.



The receiving surface of the appliance must:


- Allow solid fixing (preferably concrete).
- Withstand a weight exceeding that of the appliance.
- Have a permeable area below the condensate drain hole (soil, gravel bed, sand, etc.).
- Not transmit any vibrations to the home. It is advisable to install the anti-vibration supports supplied with the heat pump.

If the appliance is installed on wall mounts it will be particularly important to insulate it against transmission of vibration and noise to the inside of the home, and anti-vibration supports better suited to the wall mount may need to be installed in addition to those supplied with the heat pump. However, installation on the ground is the most advisable.

**Correctly level** the heat pump to ensure the condensation water cannot run out of any area except the drain hole envisaged for this purpose.


## 6.4 Condensate Drainage

During normal functioning, large amounts of water may run off from the heat pump, and the **Dual Clima HT EC** heat pump is therefore equipped with two drain holes (**A**) on the underside of the appliance. Ensure these holes are not obstructed on installation of the appliance.




- A:** Condensate drain hole (view of underside of appliance).  
**B:** Indication of front of appliance (discharge side).

The appliance should preferably be installed in a well-drained place. To do this, it is advisable to provide a bed of gravel, sand or similar materials below the drain hole. If the heat pump drain hole is covered by a mounting base or by the floor, raise the unit to leave a free space of at least 100 mm below it.



If it is installed on a terrace or façade, the condensate outlet must lead to a drain to avoid inconvenience and/or damage caused by dripping condensate water. If the installation is made in a region with long periods of sub-zero temperatures, check that there is no danger from frost.



## 6.5 Hydraulic installation


The hydraulic installation must be made by qualified personnel. The applicable installation legislation is to be complied with, and the following recommendations should also be taken into account:

- It is advisable to use suitable piping for the installation, so that the minimum flow in the hydraulic circuit is reached. The inside of the installation piping should be thoroughly cleaned before switching on the heat pump.
- All the water circuit pipes **MUST** be insulated to prevent condensation from forming during cooling mode functioning and the subsequent reduction of cooling and heating capacity, and to prevent the external pipes from freezing in winter. The minimum insulation thickness of the pipes must be 19 mm (0.039 W/mK), preferably comprising closed cell insulation or a vapour barrier. In outdoor areas exposed to the sun, the insulation must be protected from the effects of its degradation.
- For the correct operation of the heat pump, you must ensure that the pipes do not exceed maximum lengths for each model. If these lengths are exceeded, the heat pump may have operating problems and generate various alarms and lockouts. Depending on the **Dual Clima HT EC** model and the type of pipe installed, these values will be:

Copper pipe (Lmax)					
Ø	6HT	9HT	12HT/12HTT	16HT	16HTT
18	32m	9m	4m		
22	48m	32m	12m	8m	8m
28			44m	28m	28m
35				48m	48m

Multilayer pipe (Lmax)					
Ø	6HT	9HT	12HT/12HTT	16HT	16HTT
20	22m	8m			
25	48m	32m	12m	8m	8m
32			44m	28m	28m
40				48m	48m

These lengths correspond to the total length of the heat pump piping, considering both the going and the return to the installation.



**IMPORTANT:** It must be taken into account that any element added to the installation, such as elbows, filters, 3-way valves... will reduce this maximum available distance due to the pressure loss they generate in the installation.

- We recommend inserting cut-off valves between the installation piping and the heat pump to simplify maintenance tasks.
- Leave a free space around the heat pump for carrying out any maintenance and repair operations (see "*Location*").
- Air vent valves and suitable devices for correctly bleeding the air from the circuit during the water filling stage should be fitted.
- Install all the necessary safety elements in the installation (expansion tank, safety valve, etc.) to comply with the required installation standards.
- A **water filter** must be installed in the heat pump water circuit to prevent obstruction or narrowing of the pipes due to dirt in the installation. The filter **MUST** be installed before filling the installation with water, on the appliance's return line, to prevent dirty water from entering the heat exchanger (capacitor). The type of filter installed must be adapted to the particular characteristics of each installation (type and material of the water pipes, type of water used, water volume of the installation, etc.). The water filter must be checked at least once a year and cleaned if necessary, although in new installations it is recommended to check it a few months after commissioning.

- For correct functioning of the heat pump, a minimum volume of water in the installation and a minimum flow in the appliance's hydraulic circuit must be ensured. If the minimum flow in the heat pump is not reached it could have operating problems and trigger different alarms and stoppages. These values are as follows, depending on the **Dual Clima HT EC** model installed:

Dual Clima	6HT EC	9HT EC	12HT EC 12HTT EC	16HT EC 16HTT EC
Minimum volume (l)	35	45	60	80
Minimum flow rate (l/min)	14	20	30	38

If the water volume in the installation is lower than this value, install a buffer tank in the heating/air conditioning circuit. To prevent condensation from forming and premature deterioration of the buffer tank, make sure all the hydraulic sockets and connections are correctly insulated, particularly when it is to be used in Cooling mode.

- In multi-zone installations managed by thermostatic shut-off valves or similar, a system for maintaining the aforementioned minimum flows even when all the zones are closed must be provided (bypass valve, etc.).

### 6.5.1 Installing a DHW tank

The **Dual Clima HT EC** heat pump may (optionally) be installed together with a tank for Domestic Hot Water production. Among its aerothermics accessories, **DOMUSA TEKNIK** offers a full range of hot water tanks specially designed for use in combination with **Dual Clima HT EC** (the **Sanit HE**, **BT-Trio** and **BT-Duo HE** ranges). The hydraulic installation of the hot water tank must be made by qualified personnel, in accordance with the applicable installation legislation and the attached tank instructions.

To combine a DHW tank with the heat pump, insert the DHW temperature sensor supplied with the heat pump inside the appliance into the hot water tank bulb-holder. Also, a 3-way deflector valve (**G1**) must be installed between the external appliance and the DHW + Heating/Air Conditioning installation, so that the electronic control can divert the water in the installation to either DHW production or the Heating/Air Conditioning installation, depending on whether there is DHW demand.

**Dc:** Dual Clima HT EC heat pump.


**Ac:** Sanit HE hot water tank.

**Sa:** DHW tank sensor.

**G1:** 3-way diverter valve.

**E1:** Backup DHW element.


**Ic:** Heating/Air Conditioning installation.



A backup element may also optionally be installed (**E1**).

Likewise, as an alternative to the backup heating element, a conventional energy source (such as a gas or oil-fired boiler) can optionally be connected to the **Dual Clima HT EC** heat pump to back up DHW production, via the same electrical connection (**E1**). The DHW tank must therefore be equipped with an auxiliary pipe and/or an intermediate heat exchange system allowing hydraulic connection of this backup energy source. Among its aerothermics accessories, **DOMUSA TEKNIK** offers the range of **Sanit HE DS**, hot water tanks, which include an auxiliary pipe on their upper part and are specially designed for use in combination with **Dual Clima HT EC**.

- Dc:** Dual Clima HT EC heat pump.
- Ac:** Sanit HE DS hot water tank.
- Sa:** DHW tank sensor.
- G1:** 3-way diverter valve.
- E1:** DOMUSA TEKNIK backup boiler.
- Ic:** Heating/Air Conditioning installation.




The electrical installation of the DHW tank sensor, the 3-way valve (**G1**), and the backup element (**E1**), are made in the terminal strip in the indoor modules **Easy Connect** (see *"Indoor module installation instructions"*).

### 6.5.2 Installing a buffer tank

The **Dual Clima HT EC** heat pump can be installed in conjunction with a buffer tank (optional). Among its range of air source energy accessories, **DOMUSA TEKNIK** offers an array of buffer tanks that are especially designed for installation in conjunction with **Dual Clima HT EC** heat pumps (**BT, BTS, BT-Duo HE** and **BT-Trio**). The hydraulic installation of the buffer tank must be carried out by qualified personnel and in compliance with current installation regulations (RITE) and the instructions provided with the tank.

The electronic control unit of the **Easy Connect** indoor module has a specific function to manage buffer tank Heating and Cooling (see *"Operation with the buffer tank"*). This requires a temperature sensor to be inserted in the immersion sleeve of the buffer tank. The buffer tank temperature sensor is **not** supplied with the **Dual Clima HT EC** heat pump, so it must be purchased from **DOMUSA TEKNIK**. If the user wishes to install a DHW storage tank along with the buffer tank, a 3-way diverter valve (**G1**) must be installed between the outdoor unit and the DHW installation + a buffer tank so the electronic control unit can divert the water in the installation to DHW production or to the buffer tank, depending on whether DHW is required. The figure below show an example of the installation of a buffer tank along with a DHW storage tank:



- |   |   |
|---|---|
| <b>Dc:</b> Outdoor unit <b>Dual Clima HT EC</b> . | <b>E2:</b> Heating backup source.             |
| <b>Ac:</b> DHW tank.                              | <b>C4:</b> Heating/Cooling installation pump. |
| <b>Sb:</b> Buffer tank sensor.                    | <b>Ic:</b> Heating/Cooling installation.      |
| <b>G1:</b> DHW 3-way valve.                       |   |


Optionally, a backup heating element (**E2**) can be installed in the tank.

The wiring of the temperature sensor (**Sb**), the 3-way diverter valve (**G1**), the installation's circulation pump (**C4**) and the backup heating element (**E2**) must be connected to the terminal strips of the **Easy Connect** (indoor module (see *"Instructions for the installation of the indoor module"*)).

The buffer tank management function of the **Easy Connect** indoor module electronic control unit also automatically manages operation of the heating/cooling installation installed downstream from the buffer tank (see *"Operation with buffer tank"*). Up to 2 types of hydraulic circuits can be managed, depending on the selected room temperature device:


### **Room temperature sensor control**

In this installation a water circulation pump is installed between the buffer tank and the heat/cold outlets of the circuit and connected to the **C4** output of the indoor module (see *"Connecting the C4 installation pump"*), as well as a room temperature sensor installed inside the home and connected to the **T2** input of the indoor module (see *"Connecting the room temperature sensor"*). The electronic control unit will manage the operation of the **C4** circulation pump, depending on the temperature registered by the room sensor (see *"Operation with room sensor"*).



### **Room thermostat TA1 and/or TA2 control**


In this type of configuration, the electronic control unit is used to manage heating or cooling of up to 2 separate Heating/Cooling zones. This installation consists of 2 water circulation pumps installed between the buffer tank and the heat/cold outlets of each heating/cooling zone and connected to the **Z1** and/or **Z2** outputs of the indoor module (see *"Connecting the Z1 and/or Z2 installation pumps"*), as well as up to 2 room thermostats installed inside the home and connected to the **TA1** and/or **TA2** inputs of the indoor module (see *"Connecting the TA1 and/or TA2 room thermostats"*). The electronic control unit will use the signal received at inputs **TA1** and/or **TA2** of the indoor module to activate or deactivate operation of circulation pumps **Z1** and/or **Z2**, respectively.



### 6.5.3 Filling the installation

The hydraulic installation must include a filling valve, air vents valves and the necessary hydraulic components for correctly filling it.


To fill the heat pump, open the fill valve until the manometer on the rear of the appliance shows a pressure of 1 - 1.5 bars. The heat pump has an automatic air vent (**A**) incorporated to the upper part of the flow pipe of the heat exchanger (capacitor), which must be opened during the filling process. The air should also be bled from the rest of the installation using the air bleed valves provided. The installation must be filled slowly to facilitate air evacuation from the water circuit. Close the fill valve after filling. To comfortably access the heat pump air vent valve, open side and top panels of the heat pump.



**IMPORTANT:** Switching on the heat pump with no water inside could result in serious damage.

### 6.5.4 Drainage


A blow-off valve is supplied with the **Dual Clima HT EC** heat pump, which must be fitted to the drain socket (**B**) provided in the lower part of the rear of the appliance. This valve is opened to drain the water from heat pump. To do this, connect a flexible tube (**C**) to the valve and run it to a drain. To ensure the heat pump is completely drained we recommend opening the automatic air vent (**A**) inside the heat pump, so that air enters the circuit. After draining the boiler, close the valve again and remove the flexible tube.



### 6.5.5 Installing a degasifier

The **Dual Clima HT EC** heat pump contains R290 refrigerant gas. In case of leakage, this gas can be highly flammable and safety precautions must therefore be taken. An additional safety system must be installed to prevent the gas from entering the installation in case of leakage. **DOMUSA TEKNIK will not be liable for any damages caused by failing to have a safety system in place for refrigerant leakage.**

**DOMUSA TEKNIK** advises installing a degasifier in the heat pump water circuit. If leakage occurred in the plate heat exchanger, the gas in the refrigerant circuit would be removed by the degasifier, avoiding gas accumulation in the water circuit. This degasifier must be installed in the Heating/Air Conditioning flow circuit (**IC**) (See *Diagrams and Measurements*). For further details, please carefully read the instructions supplied with the kit.





## 6.6 Outdoor unit electrical connections


The electrical installation of the **Dual Clima HT EC** heat pump and its electrical accessories must be made by qualified personnel, in accordance with the applicable installation legislation. The electrical installation must be connected so that the heat pump can be fully isolated and disconnected for the safe execution of any maintenance operations.

The electrical installation of the **Dual Clima HT EC** will **only** consist of connecting it to the general electrical supply network and in the same time connecting a 2 wire communication cable between the outdoor unit and the indoor module of communication **Easy Connect** (see "*Indoor module installation instructions*"). The rest of devices and electrical accessories of the installation (diverter valves, optional sensors, room thermostats, backup devices,...) must be connected to the terminal strip of the indoor module **Easy Connect**.


There are cable holes (**D**) on the rear of the appliance for running the hoses through to the inside. Cables exposed to external weather conditions should be protected by cable ducts or protective tubes or should be of a suitable category for use outdoors (H07RN-F hoses or higher). It is also advisable to maintain a minimum distance of 25 mm between the electrical supply cable and the communication cable, running them through independent tubes.

Also, to insert the cables in the junction box, the cable ducts (**E**) incorporated to the rear of the box must be used.

**IMPORTANT:** Ensure that the junction box is totally sealed after making all the electrical connections.



The **Dual Clima HT EC** heat pump is designed to be connected at 230 V~ 50 Hz or 400 V ~ 50 Hz (depending on the model is monophasic or triphasic) at the terminals shown in the figure (see "*Electrical Diagrams*"). The power supply terminals are located inside the appliance. To access them, open the front panel and access the front electronic cards. **Remember to earth the appliance.**



The cable dimensions must comply with the applicable laws and regulations at all times. However, the table below shows some recommended characteristics and dimensions, for guidance:

		Maximum consumption (A)	Minimum cable diameter (mm <sup>2</sup> )	Recommended fuse	Recommended hose
DUAL CLIMA 6HT EC	230 V~ 50 Hz	12	1.5	16A	H05VV-U3G (in protective tube)
DUAL CLIMA 9HT EC		14	1.5	16A	
DUAL CLIMA 12HT EC		17	2.5	25A	
DUAL CLIMA 16HT EC		27	4	32A	
DUAL CLIMA 12HTT EC	400 V 3N~ 50 Hz	6	1.5	16A	
DUAL CLIMA 16HTT EC		9	1.5	16A	

The electrical connection of the heat pump must be protected by an earth leakage circuit breaker (a high-speed switch of 30 mA (<0.1 s)).

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

**IMPORTANT:** The cable diameter indicated in the table above is for guidance purposes only, as it depends on the type of cable and installation. In any case, ensure the local regulations are complied with.

## 6.7 Freeze Protection

The **Dual Clima HT EC** is an appliance for installation on the outside of the building and it will consequently be exposed to frost during periods of extremely cold weather. Freeze protection is therefore of the utmost importance for this type of appliance, as its internal construction and the amount of water contained in it make it even more prone to freezing. If the water inside the heat pump freezes it can cause the heat exchanger to break, stopping its functioning and making costly repairs necessary.

It is therefore **compulsory** to use an anti-freeze system in the installation to prevent the water in the units from freezing. **DOMUSA TEKNIK** recommends using one of the following systems:

- **Anti-freeze liquid (Glycol):** The antifreeze liquid must be diluted with the water inside the heat pump. The concentration of glycol in the mixture must be calculated taking into account the historical minimum temperature of the climatic zone where the machine is located and the concentrations indicated by the glycol manufacturer for this minimum temperature. It is also essential to regularly check the water-glycol mixture to ensure its properties and correct mixture percentage are maintained over time (at least once a year).
- **Outdoor anti-freeze valve:** The anti-freeze valve(s) must be installed on the heat pump water circuit, preferably inside the heat pump. You **must ensure** that when they are activated they drain all the water from inside the appliance. The **Dual Clima HT EC** heat pump has two sockets for connecting two anti-freeze valves. **DOMUSA TEKNIK** offers the option of an anti-freeze valve kit, specially designed for installation on the **Dual Clima HT EC** heat pump.

In addition to these active anti-freeze safety systems, a water filter must be installed in the heat pump water circuit to prevent obstruction or narrowing of the pipes due to dirt in the installation, which would speed up the freezing process or cause the water drainage devices to malfunction. The filter **MUST** be installed before filling the installation with water, on the appliance's return line, to prevent dirty water from entering the heat exchanger. The type of filter installed must be adapted to the particular characteristics of each installation (type and material of the water pipes, type of water used, water volume of the installation, etc.). The water filter must be checked at least once a year and cleaned if necessary, although in new installations it is recommended to check it a few months after commissioning.

**DOMUSA TEKNIK's guarantee does not cover any damage caused by failing to use any of the freeze protection systems described above.**

In installations where glycol has not been added, in case of prolonged periods of absence the water must be drained from the appliance in order to prevent accidental power failures and/or heat pump failure. During periods of frost, a power outage of 30 minutes or more may cause the water to freeze.

The **Dual Clima HT EC** heat pump's electronic control has a function for protecting the water inside it from freezing during periods of frost. **For this function to remain enabled and on standby, the heat pump must be connected to the mains and have a power supply, even when it is switched off or not in use.**

The anti-freeze function will start up the circulation pumps, the compressor and other system components according to the temperature conditions it detects, both of the water and outside the home. The following sections describe the functioning of the **Dual Clima HT EC** heat pump's anti-freeze process.

### 6.7.1 DHW mode anti-freeze process

When the temperature of the Domestic Hot Water tank falls below +5°C, the system starts up the anti-freeze function, enabling DHW mode and activating circulation pumps (**C1** and **C3**) the compressor and backup output **E1**. When the water temperature in the tank reaches 15°C, the function stops. If the heat pump stays on for more than 30 minutes without reaching the indicated temperature, the DHW anti-freeze function will stop.

If the DHW temperature continues to be lower than 5°C when the anti-freeze process is complete, the heat pump will stop and an error code will appear on the display.

### 6.7.2 Heating/Cooling mode anti-freeze process

When the heat pump water temperature falls below **P25** (3°C by default) in the System Parameters (see *Settings Menu*), detected on either flow or return, the system starts up the anti-freeze function, activating the water circulation pumps (**C1** and **C2**). If the external temperature is below 15°C, the heat pump will also be started up. When the water temperature reaches 10°C or the heat pump has been running for more than 30 minutes without having reached this temperature, the anti-freeze function will stop.

If the flow or return temperature continues to be lower than **P25** when the anti-freeze process is complete, the heat pump will stop and an error code will appear on the display.

Also, if the external temperature falls below 0°C at any time, the water circulation pumps (**C1** and **C2**) will start up within a time interval defined in **P21** for one minute.

**IMPORTANT: It is compulsory to use an anti-freeze system in the installation to prevent the water in the units from freezing.**

**IMPORTANT: We do not recommend changing parameters P25 and P21. Incorrectly setting these parameters could cause failure or breakdown of the appliance.**

**NOTE: For the anti-freeze function to remain enabled and on standby, the Easy Connect indoor module must be connected to the mains and have a power supply.**

**DOMUSA TEKNIK's guarantee does not cover any damage caused by failing to use a freeze protection system in the installation.**

## 7 INDOOR MODULE INSTALLATION INSTRUCTIONS

### 7.1 Accessories Supplied


The following accessories are supplied inside the **Easy Connect** indoor module. Before installing the appliance, make sure none of these accessories are missing or damaged.



**Documentation:** Include all the necessary manuals and documents for using and installing the indoor module.



**Fixing accessories:** Include 4 screws and 4 raw plugs, to fix the module to the wall. If the screw and raw plugs are not appropriate for the typology of the wall, use appropriate ones.



**Control panel connector:** In addition to the fixing accessories, a 8 way connector is also provided to connect the control panel to the Easy Connect communication module. For a correct installation read "*Connecting the control panel*".




**Control panel connection cable:** A 5 meters cable is provided to connect the outdoor unit to the Easy Connect communication module. For a correct installation read "*Indoor module installation instructions*".

### 7.2 Location

The **Easy Connect** communication module must be installed inside the home, at a location that is well-ventilated and insulated from humidity. **Access to the front of the module is essential**, so it cannot be installed where any obstacle can impede this access.

There are 4 self-tapping screws and 4 wall fittings supplied with the remote control for wall mounting. If the self-tapping screws and wall fittings are not suitable for the selected type of wall, use suitable ones. Fasten the screws to the wall according to the instructions shown in the figure, hang the module from the holes at the rear in the position shown in the figure (with the cable feed at the bottom) and tighten the screws from the inside of the module to secure the module on the wall.



### 7.3 Conexiones eléctricas


The electrical installation of the **Easy Connect** module and its electrical accessories must be made by qualified personnel, in accordance with the applicable installation legislation. The electrical installation must be connected so that the heat pump can be fully isolated and disconnected for the safe execution of any maintenance operations.

There are cable holes on the bottom of the module for passing hoses and cables for their connection inside. Los cables expuestos a las condiciones climatológicas del exterior deberán protegerse mediante canaletas o tuberías de protección, o deberán ser de la categoría adecuada para su utilización en la intemperie (mangueras tipo H07RN-F ó superior). A su vez, será recomendable mantener una distancia mínima de 25 mm entre los cables de tensión (alimentación general, válvulas desviadoras, resistencias de apoyo, bombas de circulación, ...) y los cables de comunicación y sensorización (cable de comunicación entre unidades, sondas de temperatura, sonda ambiente, ...), conduciéndolos por tuberías independientes.

**IMPORTANTE:** Siempre que se intervenga sobre la instalación eléctrica, asegurarse de que ésta está desconectada de la red eléctrica.

#### 7.3.1 Indoor module electrical connections

The **Easy Connect** module is ready to be connected electrically to the 230 V~ 50Hz voltage at terminals **L** and **N** on the connections strip. **The equipment must be connected to ground.**




The maximum consumption of the electronic card in the **Easy Connect** module is **5 A**; therefore, **total maximum electrical consumption of all the electrical accessories that are connected cannot exceed that amount.** In addition, the total maximum electrical consumption of all the connected accessories (backup heating elements, circulation pumps, diverter valves, etc.) must be taken into account to calculate the cable sections of the module's main power supply, as well as the fuses and circuit breakers protecting the electrical installation. The dimensions of the power supply cables must comply with current standards and regulations.

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

#### 7.3.2 Connection to the outdoor unit

To ensure proper operation, the **Easy Connect** communication module must be connected to the **Dual Clima HT EC** outdoor heat pump unit by a 2-wire communications cable.

The connection is made between the **RS485 A(1)** and **B(2)** yellow terminals of the **X1** inputs strip of the **Easy Connect** communications module and the **RS485 A(22)** and **B(21)** terminals of the **Dual Clima HT EC** outdoor unit connections strip. The communications cable between the outdoor unit and the indoor module should not be more than 100 meters long (cable section between 0.25 ÷ 1.25 mm<sup>2</sup>). The cable should be connected according to the poles shown on the terminals; i.e., terminal **A** of the module to terminal **A** of the outdoor unit and the same for the **B** terminals, as shown in the following figure:




**IMPORTANT:** It is essential to connect the cables to the same terminal poles on both the Easy Connect indoor module and the Dual Clima HT EC outdoor unit.


### 7.3.3 Connecting the control panel

The control panel is supplied inside the **Dual Clima HT EC** outdoor unit and must be connected to the **Easy Connect** communications module before it is switched on. To do this, first detach the panel from the outdoor unit and mount it inside the home or directly in the front cover of the **Easy Connect** module. For easier assembly inside the home, **DOMUSA TEKNIK** provides an optional accessory to mount it on a wall.

To mount the control panel on the communications module, first knock out the pre-cut window on the front cover to remove it. Then insert the panel in the window and fasten it on the front cover by turning and tightening the flanges at the rear.



Once the panel is in place, pass the connection cable supplied with the communications module from the module to the panel and connect the end to the white "**COMM4**" terminal of the indoor module's electronic card. After this, connect the green 8-wire connector to the rear of the control panel, as shown in the following figure:




The cable supplied with the indoor module is 5 meters long. If necessary, it can be extended to a maximum distance of 50 meters (cable section between 0.25 ÷ 1.25 mm<sup>2</sup>).

### 7.3.4 Connecting a DHW sensor

When installing an DHW tank in combination with the heat pump, a temperature sensor must be installed in the hot water tank. This sensor carries out the electronic control of the heat pump, managing the domestic hot water temperature by activating DHW mode when the water in the tank falls below the desired temperature.

A DHW sensor is supplied with the **Dual Clima HT EC** heat pump. This sensor is in the documentation bag inside the appliance. The sensor is connected to the electrical terminals **T13 (19 and 20)** on the input terminal strip **X1** in the **Easy Connect** indoor module. The sensor supplied with the heat pump is 5 meters long. If necessary, it can be extended to a maximum distance of 20 metres (diameter between 0.25 and 1.25 mm<sup>2</sup>).






### 7.3.5 Connecting a DHW diverter valve (G1)

When installing an DHW tank in combination with the heat pump, a motorised 3-way diverter valve must be installed between the appliance and the installation. This valve enables the heat pump electronic control to divert the water to either the DHW tank (in DHW mode) or to the Heating/Air Conditioning circuit (in Heating or Cooling mode).

The valve is connected at electrical terminals **G1 (15)**, **L(14)** and **N(6)** (Neutral) on the **X2** output terminal strip of **Easy Connect** module. The motorised diverter valve must be either a 2-wire valve (with return spring) or a 3-wire valve with phase return. The figures below show how the motorised valve is connected:




**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

### 7.3.6 Connecting a Heating/Cooling diverter valve (G2)

If the water is to be diverted to different circuits according to whether the appliance is in Heating or Cooling mode (for radiator heating and fancoil cooling, for example), a motorised 3-way diverter valve must be installed between the appliance and the installation. This valve enables the heat pump electronic control to divert the water to either the heating circuit in Heating mode or the Air Conditioning circuit in Cooling mode.

The valve is connected at electrical terminals **G2 (16)**, **L(14)** and **N(6)** (Neutral) on the **X2** output terminal strip of **Easy Connect** module. The motorised diverter valve must be either a 2-wire valve ,with return spring, or a 3-wire valve with phase return. The figures below show how the motorised valve is connected:



**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.


### 7.3.7 Connecting a room sensor (Optional)

The electronic control unit of the **Easy Connect** indoor module can be used to optimise home comfort by installing the room temperature sensor (see *"Operation with room sensor"*).

When operation with the room sensor is enabled, the sensor measures the temperature inside the home, sends it to the **Easy Connect** indoor module and it is displayed on the control panel screen. The user can select the desired room temperature setpoint at any time (see *"Selecting temperatures"*) and can adjust the temperature according to a time schedule (see *"Time programming"*). The electronic control unit of the indoor module can adjust the operating conditions to achieve the desired degree of comfort and vary the heat pump temperature to optimise heating and cooling operation and efficiency.

Proper implementation of this option requires using the **AF sensor** supplied as an optional accessory by **DOMUSA TEKNIK**, from its range of air source accessories (in the **Dual Clima HT EC+AF** models, the **AF sensor** is supplied as standard with the product). The sensor is connected to the **T2 (11 - 12)** terminals of the **X1** input terminal strip of the **Easy Connect** communications module. The cable used to connect the room sensor should not be more than 50 meters long (cable section between 0.25 ÷ 1.25 mm<sup>2</sup>).

The **AF sensor** is designed to be installed inside the home and can be mounted on a wall. It is important to choose the right location for the sensor inside the home to achieve ideal temperature conditions. The sensor should be installed in an area that is usually occupied (living room, dining room, main bedroom or similar) and not in areas with sources of heat or cold, such as the kitchen, bathrooms, cooled storage rooms, etc. Moreover, it should be installed at 1.5 meters above the floor and as far as possible from any source of heat or cold that might interfere with the thermostat, such as windows, fire places, heaters, radiators and so on.



The temperature setpoint of the room temperature sensor can be adjusted on the electronic control unit with parameter **P119** of the "System Parameters" menu (see "*Settings Menu*"). The first step is to wait for at least 10 minutes for the temperature setpoint to stabilise (without touching the room temperature sensor). The range of temperatures that can be selected is  $-5.0\sim+5.0^{\circ}\text{C}$ . The default factory setting is  $0.0^{\circ}\text{C}$ .

### 7.3.8 Connecting an outdoor temperature sensor OTC (Optional)

The electronic control unit of the **Easy Connect** indoor module can be used to adapt home comfort to the outdoor weather conditions (see "*Outdoor temperature compensation function OTC*").


This option will require installing and using the **AF sensor** supplied as an optional accessory by **DOMUSA TEKNIK**. The sensor is connected to the **T4 (13 - 14)** terminals of the **X1** input terminal strip of the **Easy Connect** communications module. The cable used to connect the room sensor should not be more than 50 meters long (cable section between  $0.25 \div 1.25 \text{ mm}^2$ ).

The **AF sensor** is designed to be installed outside the home and can be mounted on a wall. To ensure ideal temperature conditions, it is important to choose the right place to mount the sensor. It should be located on a wall facing north, protected from rain and humidity and, insofar as possible, not affected by direct sunlight or a source of heat or cold that might interfere with temperature measurement, such as exhaust grilles, smoke stacks, etc. It should also be easy to access to perform any maintenance it may require.

### 7.3.9 Connecting a buffer tank sensor (Optional)

When a buffer tank is installed in conjunction with the heat pump, a temperature sensor should be installed in the tank, through the immersion sleeve provided for that purpose. This sensor is used by the communications module electronic control unit to manage the temperature of the water in the buffer tank. It activates heating or cooling of the heat pump, depending on the selected mode and the temperature registered inside the tank.


The buffer tank temperature sensor is **not** supplied with the **Easy Connect** communications module, so it must be purchased from **DOMUSA TEKNIK**. The sensor is connected to the **T6 (15 - 16)** terminals of the **X1** input terminal strip of the **Easy Connect** communications module. The sensor is 5 meters long. If necessary, it can be extended to a maximum distance of 50 meters (section between  $0.25 \div 1.25 \text{ mm}^2$ ).



### 7.3.10 Connecting an installation pump C4 (Optional)

When a buffer tanks is installed in conjunction with the heat pump, users have the option of installing a circulation pump in the Heating/Cooling installation, downstream from the buffer tank. The electronic control unit of the communications module can use this pump to manage the water temperature in the installation by activating or deactivating the **C4** output, depending on the status of the room sensor or room thermostats connected to the indoor module and the operating mode selected at any given time.

The pump's electrical connections are made between terminals **C4 (12)** and **N (7)** (Neutral) of the indoor module's **X2** output terminal strip. Follow the instructions in the following figure carefully to ensure proper installation and electrical connection:



### 7.3.11 Connecting a zone installation pump Z1 and/or Z2 (Optional)

When a buffer tanks is installed in conjunction with the heat pump, users have the option of installing circulation pumps to create up to 2 separate zones in the Heating/Cooling installation, downstream from the buffer tank. The electronic control unit of the communications module can use these pumps to manage the water temperature in each zone separately by activating or deactivating the **Z1** and/or **Z2** outputs, depending on the status of the **TA1** and/or **TA2** room thermostats connected to the indoor module and the operating mode selected at any given time.

The pump wiring must be connected to the **X2** outputs terminal strip of the indoor module; the pump in **Zone 1** between terminals **Z1 (29)** and **N (4)** (Neutral) and the pump in **Zone 2** between terminals **Z2 (30)** and **N (4)** (Neutral).

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

### 7.3.12 Connecting a room thermostat TA1 and/or TA2 (Optional)

When a buffer tank is installed in conjunction with the heat pump and the user decides to install the **Z1** and/or **Z2** circulation pumps described in the section above, it will be necessary to install thermostats **TA1** and/or **TA2** inside the home; these will be required to manage separate operation of each heating/cooling zone, respectively.

The wiring of the thermostats must be connected to the **X2** outputs terminal strip of the indoor module at terminals **TA1 (25 - 26)** and the thermostat for **Zone 2** at terminals **TA2 (27 - 28)**. A voltage-free contact thermostat must be used. If the installation has been designed to operate in Heating and Cooling modes, 2-wire thermostats with operating mode selection should be used.

**IMPORTANT:** The thermostats must be configured to work in the same operating mode (Heating or Cooling) as the heat pump at all times.

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.


### 7.3.13 Connecting a backup energy source for DHW (E1)

A backup heating element for DHW (optional) can be connected to the **Easy Connect** module. The element must be connected to the socket provided for this purpose on the tank.

The element is connected between electrical terminals **E1 (24)** and **N (5)** (Neutral) on the **X2** terminal strip on the communication module.

**IMPORTANT:** The output relay **E1** activating the element has a maximum consumption capacity of **1A**, so to connect an element a relay must be run between the terminals of the terminal strip and the element.

**DOMUSA TEKNIK** offers the option of a kit consisting of an element with a relay included, specially designed for installation on the **Dual Clima HT EC** heat pump.



**DOMUSA TEKNIK** offers the option of a kit consisting of an element with a relay included, specially designed for installation on the **Dual Clima HT EC** heat pump.


**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

As an alternative to the heating element, a conventional energy source such as an oil-fired, gas-fired, electrical or biomass boiler can be connected to the **Easy Connect** module. The hot water tank must therefore be equipped with an auxiliary pipe and/or an intermediate heat exchange system allowing hydraulic connection of this backup energy source.

To make the electrical connection between the backup energy source and the **Easy Connect** module, use the same terminals as previously described, i.e. **E1 (24)** and **N (5)** (Neutral). Depending on the characteristics of the installation and the type of backup boiler, the electrical connection may be made in at least two different ways:

### **Voltage connection**


This type of connection takes advantage of relay output **E1** to directly activate the energy source (switch on the boiler, activate a backup circulation pump, etc.). To make this connection, connect the communication module terminals **E1(24)** and **N (5)** to the power supply input of the boiler and/or backup installation components you wish to activate. Follow the diagram below to make a correct installation:



**IMPORTANT:** The output relay **E1** has a maximum consumption capacity of **1A**, so a relay must be inserted on connecting a boiler and/or backup installation components.

### **Voltage-free connection**

If the control input for activating and deactivating the backup energy source is voltage-free (a room thermostat input or telephone relay input, for example), you must insulate the energised output of the **Easy Connect** module from the voltage-free input of the auxiliary energy source. To do this, run a relay between the module **E1** output and the control input. Follow the diagram below to make a correct installation:




### 7.3.14 Connecting a backup energy source for Heating (E2)

A backup heating element (optional) for Heating can be connected to the **Easy Connect** module. The element must be connected to the socket provided for this purpose on the tank.

The element is connected between electrical terminals **E2 (23)** and **N (5)** (Neutral) on the output terminal strip **X2** on the communication module.

**IMPORTANT:** The output relay **E2** activating the element has a maximum consumption capacity of **1A**, so to connect an element a relay must be run between the terminals of the terminal strip and the element.



**DOMUSA TEKNIK** offers the option of a kit consisting of an element with a relay included, specially designed for installation on the **Dual Clima HT EC** heat pump.

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.


As an alternative to the heating element, a conventional energy source such as an oil-fired, gas-fired, electrical or biomass boiler can be connected to the **Easy Connect** module. In this case the heating installation must be equipped with an intermediate heat exchange system allowing hydraulic connection of this backup energy source, preferably separate from the heat pump water circuit.

To make the electrical connection between the backup energy source and the **Easy Connect** communication module, use the same terminals as previously described, i.e. **E2 (23)** and **N (5)** (Neutral). Depending on the characteristics of the installation and the type of backup boiler, the electrical connection may be made in at least two different ways:



## **Voltage connection**


This type of connection takes advantage of relay output **E2** to directly activate the energy source (switch on the boiler, activate a backup circulation pump, etc.). To make this connection, connect the communication module terminals **E2 (23)** and **N (5)** to the power supply input of the boiler and/or backup installation components you wish to activate. Follow the diagram bellow to make a correct installation:



**IMPORTANT:** The output relay **E2** has a maximum consumption capacity of **1A**, so a relay must be inserted on connecting a boiler and/or backup installation components.

## **Voltage-free connection**

If the control input for activating and deactivating the backup energy source is voltage-free (a room thermostat input or telephone relay input, for example), you must insulate the energised output of the **Easy Connect** module from the voltage-free input of the auxiliary energy source. To do this, run a relay between the module output **E2** and the boiler control input. Follow the diagram bellow to make a correct installation:



### 7.3.15 Connecting a backup pump (C1, C2 and C3)


Three circulation pumps **C1, C2 and C3** can be connected to the **Easy Connect** heat pump to increase the water flow in the appliance, if necessary, in addition to the flow obtained from its own internal pump.

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

#### Main backup pump (C1)

This circulation pump **C1** will run synchronised with the internal pump of the heat pump. The pump must be installed between the heat pump and the installation in the house before any diverter valve or water storage tank (buffer or DHW tank).


The pump is connected between electrical terminals **C1 (1)** and **N (2)** (Neutral) on the **X2** output terminal strip on the communication module. Follow the diagram below to make a correct installation:



#### Backup pump for heating and/or cooling (C2)

This circulation pump **C2** will run only when the appliance is running in Heating or Cooling mode, to increase the water flow only in the Heating Cooling installation. This element must be installed in the hydraulic circuit of Heating/Cooling between the DHW diverter valve **G1** (Heating/DHW) and the water storage element if there is any (buffer,...).


The element is connected between electrical terminals **C2 (10)** and **N (9)** (Neutral) on the **X2** terminal strip of the communication module. Follow the diagram below to make a correct installation:



### **Backup pump for DHW production mode (C3)**

This circulation pump **C3** will run only when the appliance is running in DHW mode, to increase the water flow only in the DHW installation. This element must be installed in the hydraulic circuit of DHW between the DHW diverter valve **G1** (Heating/DHW) and the DHW tank.


The element is connected between electrical terminals **C3 (11)** and **N (8)** (Neutral) on the **X2** terminal strip of the communication module. Follow the diagram below to make a correct installation:



### **7.3.16 Connecting room thermostats**

The **Easy Connect** module has two connections on the component terminal strip **X1** for connecting up to 2 room chronothermostats or room thermostats (see "*Connection Diagram*"), enabling the heating and/or cooling modes of the heating/air conditioning installation to start up or stop, switching off the heat pump when the desired room temperature is reached and switching it on when the temperature in the home falls below this value. The input **C-COM (2-3)** activates and deactivates Cooling mode and the input **H-COM (1-4)** activates and deactivates Heating mode, and the operating modes of the heating/air conditioning installation are therefore managed automatically and remotely ("**AUTO**" mode) from the location of the room thermostat(s) installed.

Terminals **H-COM** and **C-COM** are supplied by default with a bridge connected to each one, so **both** bridges will have to be removed before connecting the room thermostat(s), regardless of the configuration of the thermostats to be installed.




Up to 4 different room thermostat configurations may be installed, depending on the type of thermostat or combination of thermostats used. The following sections provide a detailed description of the functioning and installation of each of these configurations.

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.


### Connecting a switched 3-wire Hot/Cold thermostat ("AUTO" mode)

As well as selecting the desired temperature and operating times, if the type of thermostat used is a chronothermostat the user can select the operating mode (Heating ☀/Cooling ❄ ) on the thermostat itself.

This type of thermostat uses 3 communication wires to function: one for the Heating mode activation signal, one for the Cooling mode activation signal and the other for the common signal. According to the status of each signal, the **Easy Connect** module manages the Heating/Cooling operating modes as follows:




Terminals **H (1)**, **C (2)** and **COM (3-4)** are supplied by default with a bridge connected to each one, so on installing this type of thermostat **both** bridges will have to be removed and the thermostat connected as shown in the figure below:




**Connecting a 2-wire Hot/Cold switching thermostat**

With this type of thermostat, the desired temperature and the operating times can be selected, if it is a chronothermostat. Unlike a 3-wire hot/cold switching thermostat, a 2-wire thermostat does not allow operating mode selection (Heating☀/Cooling❄ ) on the thermostat alone: the operating mode has to be selected on both the thermostat and the heat pump. For this room thermostat selection process to function correctly, the heat pump and the thermostat must both be configured **for the same single operating mode**, either Heating or Cooling.

As indicated in the figure, the heat pump electronic control will begin to work in “Manual” mode if this is required by the thermostat, i.e. the Heating/Cooling operating modes must be selected manually on the heat pump control panel.



Terminals **H (1)**, **C (2)** and **COM (3-4)** are supplied by default with a bridge connected to each one, so on installing this type of thermostat **both** bridges will have to be removed and the thermostat connected as shown in the figure below, and a bridge between inputs **H (1)** and **C (2)** will be required:



## Connecting two room thermostats


In this type of configuration 2 single room thermostats are connected, one to terminals **C (2)** and **COM (3)** (thermostat for Cold, **TAF**) and the other to terminals **H (1)** and **COM (4)** (thermostat for Heat, **TAC**). Each one will manage a different operating mode, and each thermostat must therefore be of a type compatible with the operating for which it has been installed. The thermostat connected to the cold input (**TAF**) must send a request (closed circuit signal) when the room temperature is higher than the desired temperature (setpoint temperature), and the thermostat connected to the heat input (**TAC**) must send a request (closed circuit signal) when the room temperature is lower than the desired temperature (setpoint temperature).

The **Easy Connect** module will activate the Heating/Cooling operating modes according to the status of the signal received from each thermostat, as follows:

Heating mode	Cooling mode	OFF (standby) (temp. reached)	Manual mode

As indicated in the figure, the heat pump electronic control will begin to work in "Manual" mode if the room thermostat setpoint temperatures are selected so that both of them send an operating request at the same time, i.e. the Heating/Cooling operating modes must be selected manually on the heat pump control panel. To avoid this situation, it is essential to **ensure that the correct temperatures are selected on each one, in order to prevent crossover, with both thermostats being activated at the same time.**


Terminals **H (1)**, **C (2)** and **COM (3-4)** are supplied by default with a bridge connected to each one, so to install the thermostats **both** bridges will have to be removed and the thermostats connected as shown in the figure below:



## Connecting one room thermostat

In this type of configuration one single thermostat is connected, either to the input **C (2)** and **COM (3)** (thermostat for Cold, **TAF**), or to the input **H (1)** and **COM (4)** (thermostat for Heat, **TAC**). For this room thermostat management setting to function correctly, the heat pump must be configured for **one single** operating mode, either Heating or Cooling (see "*Heat pump configuration*"). Depending on which input the thermostat is connected to, it will manage the corresponding operating mode and the type of room thermostat must be able to do this. The thermostat connected to the cold input (**TAF**) must send a request (closed circuit signal) when the room temperature is higher than the desired temperature (setpoint temperature), and the thermostat connected to the heat input (**TAC**) must send a request (closed circuit signal) when the room temperature is lower than the desired temperature (setpoint temperature).


Terminals **H (1)**, **C (2)** y **COM (3-4)** are supplied by default with a bridge connected to each one, so on installing the thermostat **both** bridges will have to be removed and the thermostat connected as shown in the figure below, according to the mode to be managed:





### 7.3.17 Connecting SG Ready

The **Easy Connect** module has two connections on the **X1** component terminal strip for connecting 2 inputs for the SG Ready function (see "*Connection Diagram*"), enabling management of the SG function. The input **SG1 (7-8)** activates and deactivates the SG1 connection and the input **SG2 (9-10)** activates and deactivates the SG2 connection, for remote automatic management of the operating modes of the SG Ready function. (see "*SG Ready function*").



**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

### 7.3.18 Connecting a humidity switch sensor (Optional)

Another option is to connect a humidity sensor to the **Easy Connect** indoor module to protect the installation from condensation (see "*Additional functions*").

The humidity sensor must have an output for a voltage-free relay; thus, the contact will stay open unless a hazardous degree of humidity is detected, in which case the contact will close. The humidity sensor will be connected to the **Hu (5 - 6)** terminals of the **X1** input terminal strip of the indoor module. When the electronic control unit detects a closed circuit signal in the **Hu** input, it will activate the anti-humidity protection and when it detects an open circuit signal, it will restore normal heat pump operation.


Regardless of the type of humidity sensor chosen by the user, it should be placed where condensation is most likely to appear first. The sensor should not be located near sources of heat or cold that can cause incorrect readings. An incorrect reading of the humidity sensor can interfere with the activation of the anti-humidity function and result in hazardous situations for people (e.g., slips due to wet floors) and damage caused by humidity.

**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

### 7.3.19 Connecting an energy meter (Optional)

There is also the option of connecting an energy meter to the **Easy Connect** indoor module to enable the use of solar power (see "Additional functions").

The energy meter is the **SDM230**, one of our air source energy accessories, which must be purchased from **DOMUSA TEKNIK**. The meter will communicate with the indoor module using the **RS485 Modbus** communication protocol to send the surplus energy information generated by the home's photovoltaic installation. Therefore, **the meter will have to be installed between the home's main power supply and the consumption points covered by the solar installation.**



**Dc:** Outdoor unit **Dual Clima HT EC**.

**Pc:** Consumption points.


**Pv:** Photovoltaic panels.

**Me:** Energy counter **SDM230**.

**Iv:** Solar inverter.


**Re:** Main electrical power supply.

The **SDM230** device is a **bidirectional** energy meter so it is essential to connect it to the home electrical supply according to the correct sequence and poles. Otherwise, the information sent to the electronic control unit of the indoor module will not be correct and the energy from the main power supply will be consumed instead of the energy produced by the solar installation. The **SDM230** energy meter must be connected to the main power supply between terminals **L<sub>in</sub>-N<sub>in</sub> (1 - 2)** and **L<sub>out</sub>-N<sub>out</sub> (3 - 4)** provided in the metering device. The voltage line from inside the home to the main power supply must be connected to terminals **1 - 2** and the line entering the home from the main power supply must be connected to terminals **3 - 4**, as shown in the following figure:




**IMPORTANT:** Before carrying out any work on the heat pump electrical installation, ensure it is disconnected from the mains.

The connection between the energy meter and the indoor module is made between the **RS485 A(1)** and **B(2)** yellow terminals of the **X1** inputs strip of the **Easy Connect** module and the **A(5)** and **B(6)** terminals of the energy meter communication terminals strip. The communications cable between the meter and the indoor module should not be more than 100 meters long (cable section between  $0.25 \div 1.25 \text{ mm}^2$ ). The cable should be connected according to the poles shown on the terminals; i.e., terminal **A** of the module to terminal **A** of the meter and the same for the **B** terminals, as shown in the following figure:



**IMPORTANT:** It is essential to connect the cables to the same terminal poles on both the **Easy Connect** indoor module and the **Dual Clima HT EC** outdoor unit.

Lastly, once the energy meter is supplied with power, the device's communication address should be set to **2 (Add 002)** on the device's front panel screen. To do this, use the 2 buttons at the bottom of the screen; use the (Scroll) button to navigate through the various screen options and adjust the settings of a parameter and use the (Enter) button to save the new setting after adjusting it. The (Enter) button must remain pressed for 3 seconds to access a parameter and then to save it. To adjust the communication address, use the button to navigate until the "**Add 001**", screen appears and then change the setting as shown in the following figure:




After installing and setting up the energy meter, use parameter **C69** of the "Status Parameters" menu (see "*Settings Menu*") to verify the energy sent by the meter. Make sure that this amount matches the amount displayed on the panel of the **SDM230** device. A positive amount indicates a surplus of electrical power produced by the photovoltaic solar installation, whereas a negative value indicates that energy is being consumed from the electrical power supply.

### 7.3.20 Cascade installation (Optional)

The electronic control unit of the indoor module can manage cascade operation, in both Heating and Cooling modes, of up to 4 **Dual Clima HT EC** outdoor units (see *"Additional functions"*).


However, this will require each outdoor unit to operate in conjunction with an **Easy Connect** indoor module (see *"Connection to the outdoor unit"*). Also, as a minimum, the installation must have a buffer tank for the outdoor units connected in cascade to work with, in addition to a buffer tank temperature sensor for each one (see *"Connecting a buffer tank sensor"*). The DIP-Switch **SW3-1** must be set to **ON** in each **Easy Connect** indoor module to enable cascade operation. This is done by disconnecting the power to the **Easy Connect** indoor module switching the **SW3-1** switch to **ON** and connecting the power again to the indoor module.



The outdoor units must be numbered **1** to **4**, (see *"Additional functions"*), where the **Dc1** heat pump is the main unit and the rest are secondary units that will start up one after another if the main unit cannot achieve the cooling or heating temperature setpoint. The **E3** (Heating) and **E4** (Cooling) outputs of the main **Easy Connect** indoor module (**Dc1**) must be connected to the **TAC** (Heating) and **TAF** (Cooling) inputs of the rest of the cascade system indoor modules, as shown in the figure. To manage cascade operation in **Heating mode**, this connection must be made between terminals **E3 (21 - 22)** of the **X2** outputs strip of the main module (**Dc1**) and terminals **TAC (1 - 4)** of the **X1** inputs strip of the rest of the indoor modules installed in cascade. To manage cascade operation in **Cooling mode**, the connection must be made between terminals **E4 (19 - 20)** of the **X2** outputs strip of the main module (**Dc1**) and terminals **TAF (2 - 3)** of the **X1** inputs strip of the rest of the indoor modules installed in cascade.

Apart from providing power to the cascade system, the main unit (**Dc1**) can also manage several other options: the production of DHW by a DHW storage tank connected to it, operation of backup power supplies **E1** and **E2**, operation of installation pump **C4** or zone pumps **Z1** and/or **Z2**, operation with the room sensor, the SG Ready function or the solar energy function (see *"Additional functions"*), if they are available. For proper installation and configuration of these functions in the main unit (**Dc1**), follow the installation and operation instructions for each function explained in this manual.

The following figure shows a schematic of the hydraulic circuit and an electrical connections diagram of four **Dual Clima HT EC** heat pumps installed in cascade:



**Dc1, Dc2, Dc3, Dc4:** Heat pumps in cascade.

**G1:** DHW 3-way valve G1.

**Bt:** Buffer tank.

**Ac:** DHW tank.

**S1, S2, S3, S4:** Buffer tank sensor.

**Sa:** DHW sensor.

**E1:** DHW backup source.

**E2:** Heating backup source.

Once the hydraulic and electrical connections described in this section have been made, carefully read "*Operation in cascade*" in the "*Additional functions*" section of this manual to configure the parameters for proper operation in cascade.

## 8 HEAT PUMP CONFIGURATION

---

The default configuration of the **Dual Clima HT EC** heat pump is Heating, Cooling and DHW production. If the installation lacks any of these services they **MUST** be disabled, by adjusting the system parameters on the control unit (see *"Settings Menu"*). If any of them is disabled, the operating modes (**10**) for the service in question cannot be selected.

### **Disabling DHW production**

If the installation does not have a storage tank for DHW production, this mode must be disabled. To disable this function, adjust parameter **P63** of the System Parameters (see *Settings Menu*). By default, the heat pump is supplied with DHW production enabled. To disable it, set parameter **P63** to **0**. You must also disconnect the heat pump from the mains and connect it again to validate this change.

### **Disabling the Heating or Cooling function**



If the installation does not have a water circuit designed to work in heating mode (underfloor heating, radiators, etc.) or cooling mode (underfloor cooling, fan coils, etc.), these modes must be disabled. To disable these functions, adjust parameter **P62** of the System Parameters (see *Settings Menu*). By default, the heat pump is supplied with the heating and cooling functions enabled.


To disable heating mode, set parameter **P62** to **1**. The heat pump will automatically enable cooling mode. You must also disconnect the heat pump from the mains and connect it again to validate this change.



To disable cooling mode, set parameter **P62** to **2**. The heat pump will automatically enable heating mode. You must also disconnect the heat pump from the mains and connect it again to validate this change.

**IMPORTANT:** Leaving a function enabled if the installation is not designed to work with it can cause malfunctioning of the heat pump and **SERIOUS** damage to the installation.





## 9 TIME PROGRAMMING

The electronic control of the **Dual Clima HT EC** pump includes a time programmer (7) for programming its switch-on and switch-off times and the desired operating modes for each one (weekly programming). To accede to the time programming, press the programming menu touch button  on the start screen. Press the home touch button  to exit the menu and return to the start screen.





Up to 4 time intervals can be programmed for each day of the week. The desired operating modes can be activated () and the corresponding temperature setpoints can be adjusted for each time interval. The heat pump will only run during the programmed time intervals that are activated, () , so it is not necessary to use all the programs.

Take the following steps to program a time interval:

- Select a day of the week.
- Choose the time the interval starts. Programming consecutive time intervals will not function correctly unless there is at least a 5 minute span between the start of an interval and the end of the previous interval.
- Choose the time the interval ends. Programming consecutive time intervals will not function correctly unless there is at least a 5 minute span between the end of an interval and the start of the next interval.
- Press the corresponding white box , to select the operating modes that are going to be active during the time interval in question.
- Adjust the temperature setpoints as desired for each operating mode selected in the previous step.
- Activate the programming periods by pressing the  touch button:
  -  : Time interval activated.
  -  : Time interval deactivated.

**NOTE: For proper operation of the time programming and the heat pump, do not set different programming periods during the same time interval.**

After setting the time program, the  status indicator will appear on the home screen of the control panel, indicating that time programming has been enabled. To restore manual operation of the heat pump using the  touch button, **all the periods activated in the time program must be deactivated.**







## 10 ADDITIONAL FUNCTIONS

---

### 10.1 Operation in cascade

The electronic control unit of the **Easy Connect** indoor module can manage cascade operation, in both Heating and Cooling modes, of up to 4 **Dual Clima HT EC** outdoor units. This function activates Heating or Cooling of the water in a buffer tank in outdoor units installed in cascade (see "Installation in cascade"). In addition, the main unit (**No. 1**) can also manage several other options: the production of DHW by a storage tank connected to it, operation of backup power supplies **E1** and **E2**, operation of installation pump **C4** or zone pumps **Z1** and/or **Z2**, operation with the room sensor, the SG Ready function or the solar energy function, if they are available. For proper configuration and management of these functions in the main unit, follow the installation and operation instructions for each function explained in this manual.

To enable this function in cascade, first set parameter **P121** of the "System Parameters" menu to **1** in each heat pump (see "*Settings Menu*"). After setting these parameters, set the **P132** parameter of each unit to number the outdoor units from **1** to **4**, where heat pump **No. 1** is the main unit and the rest are secondary units that will start up one after another if the main unit cannot achieve the cooling or heating temperature setpoint. Status icons , ,  or , will be displayed on the home screen of the control panel in each indoor module, indicating that operation in cascade is enabled and the number of the corresponding heat pump in the switch on/off sequence.


The switch on/off sequence in cascade is configured by adjusting the temperature hysteresis settings for each outdoor unit in parameters **P133** (no. 1), **P134** (no. 2), **P135** (no. 3) and/or **P136** (no. 4), respectively. **These parameters must be set to the same setting in all the heat pumps comprising the cascade installation.** The electronic control unit of each **Easy Connect** module in cascade will switch its corresponding heat pump on or off depending on the selected hysteresis setting and the real temperature of the buffer tank, registered by the sensor connected to it, as shown in the following figure.

Lastly, to activate operation in cascade, select the desired operating mode, Heating or Cooling, in the main indoor module (**no. 1**) (see "*Operation*") and select **the same temperature setpoint of the buffer tank** for that mode in each heat pump comprising the cascade (see "*Selecting temperatures*").


**NOTE: The hysteresis parameters (P133, P134, P135 and P136) and the operating temperature setpoints must be the same in all the heat pumps installed in cascade.**

The following diagrams describe the switch on/off sequence for each **Dual Clima HT EC** outdoor unit, depending on the operating mode selected in the main unit:

### Heating mode



### Cooling mode



## 10.2 Solar energy utilisation function

When the **Dual Clima HT EC** heat pump is installed in a home equipped with a photovoltaic solar installation, this function can be used for the electronic control unit of the indoor unit to make use of the **surplus** of electrical power generated by the photovoltaic solar installation by storing it as thermal energy in the installation's water storage tanks (DHW and/or buffer tank). This is achieved by installing an energy meter in the main electrical power supply that continuously reads the energy surplus flowing into the grid. When the surplus is sufficient to switch on the heat pump, the pump will be activated to superheat the DHW storage tank and/or superheat or subcool the buffer tank by changing their temperature setpoints. The electronic control unit will continuously adjust the power consumed by the heat pump to the amount of surplus energy. The "☀" status icon will be displayed on the home screen of the control panel, indicating that the solar utilisation function is active. The heat pump will switch off if it detects that the surplus energy is not enough to keep it running or new temperature setpoints have been reached in the storage tanks.

For optimal use of surplus solar energy, this function should be enabled in installations that have both a DHW storage tank and a buffer tank.

This operating mode cannot be enabled until an energy meter is installed and connected to the **Easy Connect** indoor module (see *"Connecting the energy meter"*). To enable this function, set parameter **P126** of the "System Parameters" menu to **1** (see *"Settings Menu"*).

Once the function is enabled, parameters **P127** (buffer tank superheating), **P128** (buffer tank subcooling) and **P129** (DHW storage tank superheating) of the "System Parameters" menu (see *"Settings Menu"*) can be used to adjust the superheating and/or subcooling setpoints of the tanks in the installation. When the solar energy utilisation function is activated, the heat pump will superheat and/or subcool these tanks to reach the new setpoints set in these parameters, provided there is a continuous surplus of electrical energy produced by the photovoltaic solar energy installation during the entire process. For the solar energy utilisation function to be effective, the superheating and subcooling setpoints must be respectively higher and lower than those set for normal operation of the heat pump.

The **P130** parameter of the "System Parameters" menu (see *"Settings Menu"*) can also be used to set the minimum energy surplus required to activate the solar energy utilisation function. The setting of this parameter will vary depending on the model of the **Dual Clima HT EC** outdoor unit and it is not recommended to change the factory setting of each model. This parameter should be changed by qualified personnel: a setting that is too low can cause fire or frequent switching off of the outdoor unit and a setting that is too high can cause loss of function and waste of energy surpluses. A correct setting must take into consideration the most extreme weather conditions expected in the region where the outdoor unit is installed, during which the **consumption required to switch on** the outdoor unit will be maximum.



### 10.3 Installation condensations protection function


When the heat pump is running in Cooling mode, condensation and damp areas can appear in the installation, depending on the type of installation (e.g., underfloor cooling), the temperature setpoint of the heat pump, the climate zone, orientation of the home and the relative humidity at the time. This can generate hazardous conditions for the persons in the home (e.g., slips on wet underfloor cooling surfaces), as well as damage caused by the humidity. To prevent condensation, be specially careful when choosing the Cooling setpoint. It should not be lower than the dew point for the inside of the home when relative humidity is high.

In addition to following the recommendations explained above, the electronic control unit of the indoor module is provided with a function for the prevention of hazardous condensation in the installation. A humidity sensor is installed in the cooling circuit or in the area of the home presenting the highest risk (see "Connecting a humidity switch sensor" and when the sensor signal is triggered, the electrical control unit will change the heat pump flow temperature to prevent condensation in the installation and even switch off the heat pump if the hazard cannot be eliminated. The "💧" status icon will be displayed on the home screen of the control panel, indicating that the protection function is active. Once the humidity sensor signal is reset and a reasonable period of time has elapsed, the heat pump will switch on again.

This function cannot be enabled until a humidity sensor is installed and connected to the **Easy Connect** indoor module (see "*Connecting a humidity switch sensor*"). To enable this function, set parameter **P125** of the "System Parameters" menu to **1** (see "*Settings Menu*").

## 11 USER MENU

The **Dual Clima HT EC** module electronic control has a User Menu (8) for the user to configure, manage and view different functions. To accede to the User menu, press the user menu touch button  on the start screen. Press the home touch button  to exit the menu and return to the start screen.



### Language

Several languages are available on the **Dual Clima HT EC** heat pump electronic control unit, and the preferred language can therefore be set. When a language is selected, it will be used on all the displays, menus, and descriptions.

### Sound adjustment

This option can be used to adjust or mute the touch screen sound volume.

### Graphics



The **Dual Clima HT EC** heat pump has an option for measuring the renewable energy generated in the installation. This option can be used to consult the renewable energy generated by the heat pump each day, month, or year.


### User settings

This option is for accessing the user settings. Only the user-adjustable settings that do not affect the heat pump's functioning are available on this sub-menu. There follows a list of the settings that can be adjusted by the user.

Code	Definition	Range	Default value
<b>P15</b>	Night mode start time.	0-23 (time)	22
<b>P16</b>	Night mode switch-off time.	0-23 (time)	6
<b>P17</b>	Night mode activation	0 (Disabled) 1 (Enabled)	0



## 12 SETTINGS MENU

The **Dual Clima HT EC** module electronic control has a Settings Menu (9) for the user to accede and configure and view different **technical parameters**, functions and statuses. To accede to the Settings menu, press the settings menu touch button  on the start screen. Press the home touch button  to exit the menu and return to the start screen.



### 12.1 System Parameters

The Settings menu allows to manage all the technical parameters (**P**) who affect the operating of gas and water circuits of the **Dual Clima HT EC** heat pump. Any incorrect adjustment of the settings in this sub-menu could cause failure and/or breakdown of the appliance, and most of the system parameters must therefore only be adjusted by authorised staff (installer, Technical Assistant Service,...).

To accede to the sub-menu of the Setting menu, enter password "99". Once in the menu, press  and  buttons to browse through the setting parameters. Press the value of the current parameter to display the numeric screen to adjust the value and validate it by pressing "**Enter**".

There follows a list of the settings that can be adjusted by the installer. Any adjustment of settings not on this list could cause serious failure and/or breakdown of the heat pump and **DOMUSA TEKNIK** will not be held liable for any damage caused by their incorrect modification by **unauthorised persons**.

Code	Definition	Range	Default value
<b>P02</b>	Heating temperature setpoint	10~75°C	45°C
<b>P03</b>	Cooling temperature setpoint	7~25°C	12°C
<b>P04</b>	DHW setpoint temperature	10~75°C	45°C
<b>P10</b>	Interval of days for anti-legionella	7~ 99 days	7
<b>P11</b>	Anti-legionella function start time	0~23	23
<b>P12</b>	Anti-legionella duration	5~99 minutes	10
<b>P13</b>	Anti-legionella setpoint	50 ~ 70 °C	70°C
<b>P14</b>	Anti-legionella function	0 (Auto Mode) 1 (Manual Mode) 2 (Disabled)	2
<b>P20</b>	Circulation pump operating mode (C1)	0: Always running 1: Stop on reaching setpoint 2: Start-up every 15 minutes	0
<b>P21</b>	Anti-freeze interval	5~50min	30
<b>P22</b>	External temp. activating backup heating (E2)	-30~20°C	0°C
<b>P23</b>	External temp. activating backup DHW (E1)	-30~20°C	0°C
<b>P24</b>	Hysteresis activating E1 and E2	1~15°C	5°C

<b>P25</b>	Anti-freeze activation temperature	-15~5°C	3°C
<b>P35</b>	Maximum DHW temperature with compressor	0~70°C	70°C
<b>P36</b>	E1 and E2 activation time interval	0~999 min	5
<b>P58</b>	Flow-return temperatures difference setpoint for Heating mode.	3~8 °C	5 °C
<b>P59</b>	Minimum C1 circulation pump speed	2~8 (20% - 80%)	8
<b>P62</b>	Heating/cooling mode activation	0: Heating + cooling 1: Cooling only 2: Heating only	0
<b>P63</b>	DHW mode activation	0: Disabled 1: Enabled	1
<b>P81</b>	E1 and E2 operating mode	0: Backup source mode 1: Auxiliary source mode 2: Passive combined mode	0
<b>P82</b>	External temp. activating auxiliary source	-30~20°C	-15
<b>P116</b>	Room sensor function	0: Disabled 1: Enabled	0
<b>P117</b>	Hysteresis for activation with room sensor in Heating mode	0,2~5 °C	0,5 °C
<b>P118</b>	Hysteresis for activation with room sensor in Cooling mode	0,2~5 °C	0,5 °C
<b>P119</b>	Correction for recorded room temperature	-5,0~+5,0 °C	0,0 °C
<b>P120</b>	K curve for OTC operating mode	0: OFF; 0,2~6	OFF
<b>P121</b>	Buffer tank function	0: Disabled 1: Enabled	0
<b>P122</b>	Hysteresis for heating or cooling activation with buffer tank	5~40 °C	5 °C
<b>P123</b>	Buffer tank heating setpoint	0: OFF; 10~75 °C	OFF
<b>P124</b>	Buffer tank cooling setpoint	0: OFF; 7~25 °C	OFF
<b>P125</b>	Condensations protection function	0: Disabled 1: Enabled	0
<b>P126</b>	Solar energy utilisation function	0: Disabled 1: Enabled	0
<b>P127</b>	Solar reheating setpoint for buffer tank	0: OFF; 10~75 °C	OFF
<b>P128</b>	Solar re-cooling setpoint for buffer tank	0: OFF; 7~25 °C	OFF
<b>P129</b>	Solar reheating setpoint for DHW tank	0: OFF; 10~70 °C	OFF
<b>P130</b>	Power excess to activate solar energy utilisation function	750 W~5250 W	<b>Dual Clima 6HT EC:</b> 1450 W <b>Dual Clima 9HT EC:</b> 2300 W <b>Dual Clima 12HT EC:</b> 3100 W <b>Dual Clima 16HT EC:</b> 4500 W
<b>P132</b>	Operation in cascade	0: Disabled 1~4: Cascade numeration	0
<b>P133</b>	Hysteresis for activation of n°1 heat pump in cascade (dT1)	1~40 °C	5 °C
<b>P134</b>	Hysteresis for activation of n°2 heat pump in cascade (dT2)	1~40 °C	7 °C
<b>P135</b>	Hysteresis for activation of n°3 heat pump in cascade (dT3)	1~40 °C	9 °C
<b>P136</b>	Hysteresis for activation of n°4 heat pump in cascade (dT4)	1~40 °C	11 °C
<b>P138</b>	Time programming for room sensor	0: Disabled 1: Enabled	0
<b>P139</b>	Flow-return temperatures difference setpoint for Cooling mode.	3~8 °C	5 °C
<b>P201</b>	SG Ready function activation	0: disable, 1: enable	OFF





<b>P202</b>	Recommended heating switch-on setpoint	OFF, 10°C~75°C	OFF
<b>P203</b>	Heating switch-on setpoint	OFF, 10°C~75°C	OFF
<b>P204</b>	Recommended cooling switch-on setpoint	OFF, 10°C~30°C	OFF
<b>P205</b>	Cooling switch-on setpoint	OFF, 10°C~30°C	OFF
<b>P206</b>	Recommended DHW switch-on setpoint	OFF, 10°C~70°C	OFF
<b>P207</b>	DHW switch-on setpoint	OFF, 10°C~70°C	OFF
<b>P208</b>	SG Ready function heating devices	0: Heat pump + E1/E2 1: E1/E2 2: Heat pump only	OFF

**NOTE:** Any settings not shown in the table are technical parameters set by default and must not be changed under any circumstances. Changing any these settings could cause malfunction and/or breakage of the heat pump.

## 12.2 Operating Status

On the sub-menu "Operating status", a descriptive diagram of the heat pump allows to **view** and check any time the status of all the heat pump's control and safety components and the values of some of the operating parameters.

Also, on the main "Operating Status" screen, you can press the **i** to access the heat pump's **C** parameters or Status parameters of the heat pump. The status parameters are display parameters, They are therefore not adjustable and their purpose is to diagnose the functioning of the appliance during maintenance and repair operations. Once in the menu, press  and  buttons to browse through the **C** parameters.

**NOTE:** The parameters labelled "Reserved" on the table do not apply to these heat pump models and are therefore not relevant.

Code.	Definition	Unit	Range
<b>C00</b>	Evaporator temperature sensor	°C	
<b>C01</b>	Discharge temperature sensor	°C	
<b>C02</b>	Outdoor temperature sensor	°C	
<b>C03</b>	Suction temperature	°C	
<b>C04</b>	Reserved		
<b>C05</b>	Reserved		
<b>C06</b>	Heat exchanger sensor temperature	°C	
<b>C07</b>	Return water temperature sensor	°C	
<b>C08</b>	Flow water temperature sensor	°C	
<b>C09</b>	DHW temperature sensor	°C	
<b>C10</b>	Water flow	l/min	
<b>C11</b>	Main temperature difference	°C	
<b>C12</b>	Reserved		
<b>C13</b>	High pressure	Mpa	
<b>C14</b>	Low pressure	Mpa	
<b>C15</b>	Compressor operating frequency	Hz	
<b>C16</b>	Fan 1 speed	rpm	
<b>C17</b>	Fan 2 speed	rpm	
<b>C18</b>	Expansion valve opening degrees	°	
<b>C19</b>	Reserved		
<b>C20</b>	Target compressor frequency	Hz	
<b>C21</b>	Compressor operating current	A	
<b>C22</b>	IPM module temperature	°C	
<b>C23</b>	Input voltage (AC)	V	
<b>C24</b>	Input voltage (DC)	V	
<b>C25</b>	Reserved		
<b>C26</b>	Reserved		


Code.	Definition	Unit	Range
<b>C27</b>	Evaporation temperature	°C	
<b>C28</b>	Condensation temperature	°C	
<b>C29</b>	TAF enabled	0/1	off: Connected, on: Disconnected
<b>C30</b>	TAF enabled	0/1	off: Connected, on: Disconnected
<b>C31</b>	Anti-legionella function	0/1	off, on
<b>C32</b>	Compressor overcurrent protection	0/1	off, on
<b>C33</b>	Defrost	0/1	off, on
<b>C34</b>	Heating anti-freeze	0/1	off, on
<b>C35</b>	DHW anti-freeze	0/1	off, on
<b>C36</b>	Compressor heating element	0/1	off, on
<b>C37</b>	4-way valve	0/1	off: Cold, on: Heat
<b>C38</b>	3-way valve G1	0/1	off: Heat/Cold, on: DHW
<b>C39</b>	3-way valve G2	0/1	off: Cold, on: Heat
<b>C40</b>	Backup energy for DHW E1	0/1	off, on
<b>C41</b>	Heating backup energy E2	0/1	off, on
<b>C42</b>	Main circulation pump C1	0/1	off, on
<b>C43</b>	Circulation pump C2	0/1	off, on
<b>C44</b>	Backup pump C3	0/1	off, on
<b>C45</b>	Heating temperature setpoint	°C	
<b>C46</b>	Cooling temperature setpoint	°C	
<b>C47</b>	DHW setpoint temperature	°C	
<b>C48</b>	Anti-legionella temperature setpoint	°C	
<b>C49</b>	Lubricant return process	0/1	0: off, 1: on
<b>C50</b>	Compressor run time	hours	
<b>C51</b>	Circulation pump C1 speed	0~100%	
<b>C52</b>	Heat pump operating mode	0/4	0: Standby, 1: DHW, 2: Heating, 4: Cooling
<b>C53</b>	Reserved		
<b>C54</b>	Selected operating mode	0/5	0: Standby, 1: DHW, 2: Heating, 3: DHW+Heating, 4: Cooling, 5: DHW + Cooling
<b>C55</b>	PCB software version	/	
<b>C56</b>	Software display version	/	
<b>C57</b>	Buffer tank temperature	°C	
<b>C58</b>	Outdoor temperature (OTC)	°C	
<b>C59</b>	Reserved		
<b>C60</b>	SG1 Input	0/1	0: Disabled 1: Enabled
<b>C61</b>	SG2 Input	0/1	0: Disabled 1: Enabled
<b>C62</b>	Humidity sensor	0/1	0: Disabled 1: Enabled
<b>C63</b>	Circulation pump C4	Off/On	Off: Disabled On: Enabled
<b>C64</b>	Reserved		
<b>C65</b>	Reserved		
<b>C66</b>	Reserved		
<b>C67</b>	Heating mode in cascade	0/1	0: Disabled 1: Enabled
<b>C68</b>	Cooling mode in cascade	0/1	0: Disabled 1: Enabled
<b>C69</b>	Power exceed measured by the energy counter device	W	
<b>C70</b>	Solar energy utilisation function	Off/On	Off: Disabled On: Enabled
<b>C71</b>	Reserved		

## 13 CONFIGURING THE AUXILIARY OR BACKUP ENERGY SOURCES (E1, E2)

The operating principle of **Dual Clima HT EC** heat pumps is to extract energy from the air outside the building and transmit it to the interior to heat or cool a water circuit for either heating/air conditioning and/or DHW production. The heating capacity of the heat pump will therefore directly depend on the amount of energy available in the air outside the building and consequently on the weather conditions (temperature and humidity) in the exterior environment.

As a result, in extremely cold weather conditions and/or if the heat pump is located in a geographical area with high humidity, it may require the aid of a backup or auxiliary energy source to achieve the desired comfort conditions. The **Easy Connect** module is therefore equipped with 2 relay outputs (**E1**, **E2**) for connecting these auxiliary energy sources, which may be heating elements, a gas boiler, an oil-fired boiler, etc. or any combination of these. One of the two outputs is for backing up DHW production (**E1**), and the other is for backup in heating mode (**E2**). For a correct installation and electrical connection, carefully read the "Indoor module installation instructions" section in this manual.

The operating mode of these outputs, according to the external temperature conditions, can be configured via parameter **P81** of the System Parameters. There are 3 different operating modes to choose from. The selection of the operating mode depends on type of installation and the typology of backup device available. Therefore, the selection of operating mode and the adjustment of correspondent parameters must be made by qualified technical personnel. The diagram below shows the energy sources available according to the external temperature and the operating mode selected for parameter **P81** of the System Parameters.



### 13.1 Backup source mode (P81 = 0)

In this operating mode, the auxiliary energy sources are activated when the external temperature falls below a value selected for parameters **P22** (Heating backup) and **P23** (DHW backup) of the "System Parameters" (see "*Settings Menu*"), to aid and complete the performance of the heat pump. The heat pump will continue running at the same time as the backup sources. This is the pre-set default operating mode.

#### Configuring the backup source for DHW (E1)

When the heat pump is running in DHW mode, the energy source connected to output **E1** will be enabled if the external temperature falls below the value selected for parameter **P23** and the heat pump is not able to reach the set DHW production conditions. When the backup energy source is activated, both the heat pump and the backup source will run simultaneously to achieve the desired performance. The selectable range of values for parameter **P23** is -30 ~ +20 °C. The pre-set default value is 0°C.

#### Configuring the backup source for Heating (E2)

When the heat pump is running in Heating mode, the energy source connected to output **E2** will be enabled if the external temperature falls below the value selected for parameter **P22** and the heat pump is not able to reach the set heating conditions. When the backup energy source is activated, both the heat pump and the backup source will run simultaneously to achieve the desired performance. The selectable range of values for parameter **P22** is -30 ~ +20 °C. The pre-set default value is 0°C.

### 13.2 Auxiliary source mode (P81 = 1)

In this operating mode, the backup energy source for Heating **E2** becomes an **alternative** source to the heat pump ("auxiliary" source). It is activated when the external temperature falls below the value selected for parameter **P82** of the "System Parameters" (see "*Settings Menu*"). The heat pump will switch off (Standby), leaving the auxiliary source **E2** running as the installation's only heat source for both Heating and DHW production. The selectable range of values for parameter **P82** is -30 ~ +20 °C. The pre-set default value is -15 °C.

In this operating mode, the **E1** backup energy source for DHW will only be activated when the temperature in the hot water tank exceeding that of **P35** of the "System Parameters" (see "*Settings Menu*") needs to be reached.

### 13.3 Passive combined mode (P81 = 2)

This operating mode is optimised for installations that combine the "Backup source mode" and the "Auxiliary source mode", using **passive** auxiliary energy sources that do not generate primary water circulation such as an electric element, a heat exchanger, etc.

When the external temperature falls below the value selected for parameters **P22** (Heating backup) and **P23** (DHW backup) of the "System Parameters", the auxiliary energy sources **E2** and/or **E1** are activated in combination with the heat pump, as described in the section "*Backup source mode*".

If the external temperature falls below the value selected for parameter **P82** of the System Parameters, the heat pump will switch off (Standby), leaving the auxiliary sources **E2** and/or **E1** as the only heat source in the installation, **E1** for DHW tank heating and **E2** for the heating installation, as described in the section "*Auxiliary source mode*".

**NOTE: When the heating auxiliary energy source (E2) is activated, the heat pump's circulation pump (C1) is also activated.**

## 14 COMMISSIONING

---

### 14.1 Prior warnings

Repair and maintenance of the heat pump must be carried out by a qualified professional authorised by **DOMUSA TEKNIK**. For optimum functioning and conservation of the heat pump, it should be serviced annually.

Please carefully read this instruction manual and keep it in a safe, easily-accessible place. **DOMUSA TEKNIK** will not be liable for any damages caused by failure to follow these instructions.

Before any servicing, **disconnect the heat pump from the mains**.

### 14.2 Commissioning

In order for the **guarantee to be valid**, the heat pump must be commissioned by **personnel authorised by DOMUSA TEKNIK**. Before beginning the commissioning process, the following must be complied with:

- The heat pump must be plugged in to the mains and the correct electrical supply must be used.
- The installation must be filled with water (the pressure must be between 1 and 1.5 bar) and correctly air bled.
- If the installation has flow and return valves, check they are open.

The commissioning process must include the following steps, at least:

- Check that the heat pump configuration is correct and corresponds to the Heating, Cooling and/or DHW modes permitted for the installation.
- Check that all the technical parameters on the Settings Menu have been correctly set, and adjust them if necessary.
- Check that the heat pump and internal piping system have not been damaged during transport.
- Check that the fan can move freely.
- Check that all the pipes are correctly insulated, particularly in the case of installations that can be used in Cooling mode.

### 14.3 Installation handover

After the initial commissioning, the Technical Assistance Service will explain to the user how the heat pump functions, making any observations they consider relevant.

The installer is responsible for clearly explaining to the user the functioning of any control or regulation device forming part of the installation but not supplied with the heat pump.

## 15 MAINTENANCE

---

To maintain the heat pump in perfect working order, a yearly overhaul should be performed by **DOMUSA TEKNIK**'s authorised personnel. Among other maintenance work, the following must be carried out at least once a year:

- Check that the supply, consumption and electrical system are all correct.
- Check that the water installation, the safety valves and the installation control devices are all working correctly.
- Check that the water circulation pump is working correctly. Make sure there are no leaks or obstructions in the water pipes and pipe accessories.
- Clean any dirt from the evaporator.
- Check that the various components of the gas circuit are functioning correctly. Inspect the pipe joints and make sure the valves are correctly oiled.
- Chemically clean the plate heat exchanger every 3 years.
- Check that the refrigerant gas content is correct.
- Check that the refrigerant gas leak safety systems are functioning correctly and are not obstructed.

## 16 RECYCLING AND DISPOSAL

---

### **Removal**

This product must be removed by personnel authorised to handle fluorinated gases.

The heat pump contains R290 refrigerant. Any leakage of refrigerant into the atmosphere must be avoided.

### **Recycling**

Take the heat pump to a waste collection point for recycling or disposal. Contact qualified personnel for the handling of fluorinated gases. Contact the installer or the local authority for more information.

### **Disposal**

Do not attempt to remove this product on your own.

Its removal and the treatment of the refrigerant, oil and other components must be carried out in accordance with local and national legislation. The entire unit, including the refrigerant gas, the compressor and the oil it contains, must be taken to a waste collection point as it could contain refrigerant residue.

All the refrigerant must be removed and returned to the manufacturer for recycling or disposal.

**IMPORTANT:** The refrigerant gas contained in the heat pump is highly flammable and can cause damage to persons or property.

## 17 TECHNICAL CHARACTERISTICS

MODEL		DUAL CLIMA 6HT EC	DUAL CLIMA 9HT EC	DUAL CLIMA 12HT EC	DUAL CLIMA 16HT EC	DUAL CLIMA 12HTT EC	DUAL CLIMA 16HTT EC
Type	-	Air/water					
Rated heating capacity	kW	6.40	9.15	12.20	16.00	12.2	16.00
Rated heating consumption	kW	1.33	2.03	2.72	3.41	2.72	3.41
Rated heating current	A	5.78	8.83	11.83	14.83	4.13	5.18
COP (Air +7°C, Water 35°C)	-	4.81	4.50	4.48	4.69	4.48	4.69
Rated cooling capacity	kW	6.25	8.85	10.80	14.85	10.8	14.85
Rated cooling consumption	kW	1.42	2.28	2.88	3.97	2.88	3.97
Rated cooling current	A	6.17	9.91	12.52	17.26	4.38	6.03
EER (Air +35 °C, Water 18 °C)	-	4.40	3.88	3.75	3.74	3.75	3.74
Maximum consumption	kW	2.76	3.15	3.75	6.21	3.75	6.21
Maximum current	A	12.0	13.7	17.0	27.0	5.7	9.4
Electrical supply	-	230 V~ / 50 Hz				400 V 3N~ / 50 Hz	
Max. working pressure: (water circuit)	MPa (bar)	0,3 (3)					
Max. water temperature	°C	75					
Nominal water flow	m³/h	1.10	1.57	2.10	2.75	2.10	2.75
Max. working pressure: (refrigerant circuit)	MPa	3.2					
Min. working pressure: (refrigerant circuit)	MPa	0.1					
Refrigerant	-	R290					
Refrigerant amount	kg	0.8	1.05	1.2	1.4	1.2	1.4
Protection degree	-	IPX4					
Working temperature range (Heating)	°C	-25/45					
Working temperature range (Cooling)	°C	10/45					
Sound pressure level (1m)	dB(A)	42	47	44	48	44	48
Dimensions: (Height/Width/Depth)	mm	1115/415/900			1115/415/1320	1115/415/900	1115/415/1320
Net weight	Kg	80	82	125	175	125	175

## 18 ELECTRICAL DIAGRAMS

---

### 18.1 Nomenclatures

#### Indoor module components:

##### **Input terminal strip X1:**

<b>TAC:</b> Heating room thermostat.	<b>T2:</b> Room sensor.
<b>TAF:</b> Cooling room thermostat.	<b>T4:</b> Outside temperature sensor (OTC).
<b>Hu:</b> Humidity sensor.	<b>T6:</b> Buffer tank sensor.
<b>SG1:</b> Contact 1 for SG Ready function.	<b>T12:</b> Not used.
<b>SG2:</b> Contact 2 for SG Ready function.	<b>T13:</b> DHW temperature sensor.
<b>A/B:</b> <b>RS485</b> communication with the outdoor unit.	<b>HMI:</b> Control panel.

##### **Output terminal strip X2:**


<b>C1:</b> Main circulation pump.	<b>E3:</b> Cascade function output for Heating mode.
<b>C2:</b> Heating/cooling backup circulation pump.	<b>E2:</b> Heating backup element.
<b>C3:</b> DHW backup circulation pump.	<b>E1:</b> DHW backup element.
<b>C4:</b> Installation circulation pump.	<b>TA1:</b> Room thermostat Zone 1.
<b>G1:</b> 3-way Heating/DHW valve.	<b>TA1:</b> Room thermostat Zone 2.
<b>G2:</b> 3-way Heat/Cold valve.	<b>Z1:</b> Circulation pump Zone 1.
<b>E4:</b> Cascade function output for Cooling mode.	<b>Z2:</b> Circulation pump Zone 2.

#### Outdoor unit components:


<b>MC:</b> Compressor motor.	<b>T3:</b> Evaporator temperature sensor.
<b>RC:</b> Compressor heating element.	<b>T5:</b> Suction temperature sensor.
<b>I:</b> Inductance.	<b>T7:</b> Outdoor temperature sensor.
<b>MV:</b> Fan motor.	<b>T11:</b> Return temperature sensor.
<b>EEV:</b> Electronic expansion valve.	<b>T12:</b> Flow temperature sensor.
<b>V4V:</b> 4-way valve.	<b>T16:</b> Internal heat exchanger temperature sensor.
<b>LS:</b> Low pressure sensor.	<b>C1:</b> Heat pump circulation pump.
<b>HS:</b> High pressure sensor.	<b>Q:</b> Flow meter.
<b>T1:</b> Discharge temperature sensor.	<b>A/B:</b> <b>RS485</b> communication with the indoor module.




## 18.2 Indoor module Easy Connect




## 18.3 Outdoor unit Dual Clima 6HT EC, 9HT EC, 12HT EC




## 18.4 Outdoor unit Dual Clima 16HT EC



## 18.5 Outdoor unit Dual Clima 12HTT EC, 16HTT EC



## 19 DIMENSIONS



	DUAL CLIMA 6HT EC	DUAL CLIMA 9HT EC	DUAL CLIMA 12HT EC 12HTT EC	DUAL CLIMA 16HT EC	DUAL CLIMA 16HTT EC
A (mm)	900	900	900	1320	1320
B (mm)	141	141	140	466	466
C (mm)	279	279	476	150	150
D (mm)	62	62	62	140	140
IC: Heating/Air Conditioning outlet	1"			1-1/4"	
RC: Heating/Air Conditioning inlet	1"			1-1/4"	
V: Water circuit draining	1/2"				
HP: Gas circuit High Pressure port	1/4" SAE				
LP: Gas circuit Low Pressure port	1/4" SAE				


## 20 CIRCULATION PUMP CHARACTERISTICS

The graphs below can be used to calculate the hydromotive pressure available in the installation at the heat pump output, considering the pump operating curve and the pressure drop of each **Dual Clima HT EC** heat pump model.


### 20.1 Circulation pump flow curves

The graphs below show the hydromotive pressure that can be reached by each **Dual Clima HT EC** model water circulation pump, according to the installation flow:


#### Dual Clima 6HT EC and Dual Clima 9HT EC



#### Dual Clima 12HT EC and Dual Clima 12HTT EC




#### Dual Clima 12HT EC and Dual Clima 12HTT EC



## 20.2 Heat pump pressure drop

The graph below shows the pressure drop generated by the internal hydraulic circuit of each **Dual Clima HT EC**, model, according to the installation flow:



## 20.3 Circulation pump adjustment

The control of **Dual Clima HT EC** heat pump manage automatically the speed of the C1 circulation pump, which is in the outdoor unit, with the aim of obtain and maintain a temperature difference between flow and return temperatures of the heat pump. The temperature difference setpoint can be adjusted with **P58** (in heating mode) and **P139** (in cooling mode) of the "System Parameters" (see "Setting menu").

In turn, parameter **P59** determine the minimum speed of the circulation pump **C1**. The pre-set default value for **P59** is 8 (80%), therefore the pump speed will be adjusted between 80% and 100% of its capacity.


## 21 PERFORMANCE AND EFFICIENCY CURVES

The operating principle of **Dual Clima HT EC** heat pumps is to extract energy from the air outside the building and transmit it to the interior to heat or cool a water circuit for either heating/air conditioning and/or DHW production. The heating capacity and efficiency of the heat pump will therefore directly depend on the amount of energy available in the air outside the building and consequently on its temperature.

### 21.1 Heating performance and efficiency curves

The graphs below show the heating capacity (power) and efficiency (COP) of each **Dual Clima HT EC** model, according to the external temperature.


#### **Dual Clima 6HT EC**






## Dual Clima 9HT EC

Dual Clima 9HT EC heating performance curves




Dual Clima 9HT EC heating efficiency (COP)




## Dual Clima 12HT EC /12HTT EC

Dual Clima 12HT EC heating performance curves




Dual Clima 12HT EC heating efficiency (COP)




## Dual Clima 16HT EC /16HTT EC

Dual Clima 16HT EC heating performance curves





Dual Clima 16HT EC heating efficiency (COP)



## 21.2 Cooling performance and efficiency curves


The graphs below show the cooling capacity (power) and efficiency (EER) of each **Dual Clima HT EC** model, according to the external temperature.

### Dual Clima 6HT EC




## Dual Clima 9HT EC

Dual Clima 9HT EC cooling performance curves




Dual Clima 9HT EC cooling efficiency (EER)




## Dual Clima 12HT EC /12HTT EC

### Dual Clima 12HT EC cooling performance curves




### Dual Clima 12HT EC heating efficiency (COP)




**Dual Clima 16HT EC /16HTT EC**


**Dual Clima 16HT EC heating performance curves**





**Dual Clima 16HT EC heating efficiency (COP)**



## 22 ALARM CODES

The **Dual Clima HT EC** boiler is equipped with an electronic control that performs continuous self-testing to detect any pump malfunctioning. When the electronic control detects an operating error, this is indicated by an alarm code and an alarm indicator light () on the main control panel display.

On the "Settings Menu" (9), on the "Operating Status" sub-menu, press the touch button  to access the alarm code menu displaying 7 last operating failures detected by the heat pump, in chronological order. To exit the menu and return to the start screen, press the touch button . The table below lists the possible alarm codes:

Code	Alarm	Description
<b>E01</b>	External temperature sensor failure.	Open circuit or short circuit in the external temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E02</b>	External heat exchanger temperature sensor failure.	Open circuit or short circuit in the external heat exchanger temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E03</b>	Suction temperature sensor failure.	Open circuit or short circuit in the suction temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E04</b>	Heat pump settings incorrect.	Check the control card SW1's and all the Settings Menu parameters. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E05</b>	Heat pump settings incorrect.	Check the control card SW1's and all the Settings Menu parameters. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E06</b>	Discharge temperature sensor failure.	Open circuit or short circuit in the discharge temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E07</b>	DHW temperature sensor failure.	Open circuit or short circuit in the DHW temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E08</b>	Flow temperature sensor failure.	Open circuit or short circuit in the flow temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E09</b>	Return temperature sensor failure.	Open circuit or short circuit in the return temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E10</b>	Internal heat exchanger temperature sensor failure.	Open circuit or short circuit in the internal heat exchanger temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E11</b>	High pressure sensor failure.	Open circuit or short circuit in the flow temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E12</b>	Low pressure sensor failure.	Open circuit or short circuit in the low pressure temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E13</b>	High pressure protection.	High pressure safety device triggered. Disconnect the heat pump from the mains and connect it again. If this



Code	Alarm	Description
		alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E14</b>	Low pressure protection.	Low pressure safety device triggered. Disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E15</b>	Insufficient water flow.	The appliance flow meter is detecting a water flow lower than the minimum permitted for each heat pump model (see " <i>Hydraulic installation</i> "). Disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E16</b>	Communication error.	Communication error between the PCB card and the display. Check the electrical connections. Disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E17</b>	Compressor gas discharge temperature too high.	The compressor discharge temperature safety device has been triggered. Contact your nearest official technical assistance service.
<b>E18</b>	Heat pump settings incorrect.	Check the control card SW1's and all the Settings Menu parameters. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E20</b>	IPM or compressor error.	The compressor or IPM has an operational problem. See E20 alarm code details. Check the installation then disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E20-1</b>	Overcurrent in IPM.	The electric current in the IPM is too high. Contact your nearest official Technical Assistance Service.
<b>E20-5</b>	Compressor failure.	The compressor is not working correctly. Check the wiring. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E20-16</b>	Low voltage in IPM.	Low voltage in IPM. Contact your nearest official Technical Assistance Service to have it repaired.
<b>E20-32</b>	High voltage in IPM.	High voltage in IPM. Contact your nearest official Technical Assistance Service to have it repaired.
<b>E20-257</b>	IPM communication failure.	Deficient communication in the IPM. Contact your nearest official Technical Assistance Service to have it repaired.
<b>E20-258</b>	Phase loss.	Power source error. Contact your nearest official Technical Assistance Service to have it repaired.
<b>E20-260</b>	AC current protection.	The power supply current is too high. The heat pump will recover when the current returns to the permitted range of values.
<b>E20-264</b>	IPM AC voltage protection.	The power supply voltage is too high, too low or unstable.
<b>E20-320</b>	Compressor overcurrent protection	The compressor electric current is too high. Contact your nearest Official Technical Assistance Service.

Code	Alarm	Description
<b>E20-288</b>	Excessive temperature in IPM.	The temperature in the IPM is too high. Contact your nearest official Technical Assistance Service.
<b>E20-298</b>	IPM protection.	Error in the IPM module. Contact your nearest official Technical Assistance Service to have it repaired.
<b>E20-299</b>	Current sensor failure.	Failure of the appliance's internal ammeter, or the power wire is not crossing it. Contact your nearest official Technical Assistance Service to have it repaired.
<b>E20-384</b>	PFC module failure in IPM.	IPM error or incorrect wiring. Disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E21</b>	Voltage error.	Voltage error in the heat pump. Disconnect and reconnect the power supply to the heat pump. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E22</b>	Large temperature difference between flow and return.	Very large temperature difference between the values measured by the flow and return temperature sensors. Check the installation then disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E23</b>	DHW mode anti-freeze function.	The DHW mode anti-freeze function has been triggered twice in the last 60 minutes. Disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E24</b>	Heating/Cooling mode anti-freeze function.	The heating/cooling mode anti-freeze function has been triggered twice in the last 90 minutes. Disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E26</b>	Heat pump settings incorrect.	Check the electrical diagram and the connector at sensor T6. Check the control card SW1's and all the Service Menu parameters. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E27</b>	Room temperature exceeds limit.	The room temperature has exceeded the upper limit permitted (45°C).
<b>E28</b>	High return temperature (cooling mode).	The temperature measured by the return temperature sensor in cooling mode is too high. Check the installation then disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E29</b>	Room temperature sensor failure.	Check the electrical diagram and the connector at sensor T2. Check the control card SW1's and all the Service Menu parameters. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E32</b>	High flow temperature (Heating and DHW mode).	The temperature measured by the flow temperature sensor in heating or DHW mode is too high. Check the installation then disconnect the heat pump from the

Code	Alarm	Description
		mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E36</b>	Fan motor communication failure (three-phase models).	Fan motor failure. Contact your nearest Official Technical Assistance Service to have it repaired.
<b>E40</b>	Low return temperature (cooling mode).	The temperature measured by the flow temperature sensor in cooling mode is too low. Check the installation then disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E44</b>	Fan motor failure.	Fan motor failure. Contact your nearest Official Technical Assistance Service to have it repaired.
<b>E50</b>	External heat exchanger sensor too high.	The external heat exchanger temperature safety device has been triggered. Contact your nearest official Technical Assistance Service.
<b>E56</b>	Current protection.	The working current has exceeded the maximum working value for the compressor. Disconnect and reconnect the power supply to the heat pump. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E58</b>	Room temperature below limit.	The room temperature has fallen below the lower limit permitted (-25°C).
<b>E59</b>	Flow and return sensors reversed or 4-way valve failure.	Flow and return temperature sensors reversed or 4-way valve failure. Check the installation then disconnect the heat pump from the mains and connect it again. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E99</b>	Communication failure.	Communication failure between the power card and the IPM. Check the wiring. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E100</b>	DHW temperature sensor failure.	Open circuit or short circuit in the DHW temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E101</b>	Room temperature sensor failure.	Open circuit or short circuit in the room temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E102</b>	Outside temperature sensor failure. (OTC)	Open circuit or short circuit in the outside temperature sensor (OTC). Contact your nearest official Technical Assistance Service to have it replaced.
<b>E103</b>	Buffer tank temperature sensor failure.	Open circuit or short circuit in the buffer tank temperature sensor. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E105</b>	Bidirectional energy counter failure.	Communication failure between the energy counter and the <b>Easy Connect</b> indoor module. Check the wiring and connection between both devices. Check the configuration of the (" <b>Addr</b> ") address in the energy counter. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.

Code	Alarm	Description
<b>E106</b>	Indoor module communication failure.	Communication failure between the <b>Easy Connect</b> indoor module and the <b>Dual Clima HT EC</b> indoor module. Check the wiring and connection between both devices. If this alarm persists or occurs repeatedly, contact the nearest Official Technical Assistance service.
<b>E107</b>	Buffer tank sensor failure in cascade function.	Open circuit or short circuit in the buffer tank temperature sensor when cascade function is enabled. Contact your nearest official Technical Assistance Service to have it replaced.
<b>E108</b>	Cascade operating setting failure.	<b>SW3-1</b> DIP-Switch is not well adjusted to enable the cascade function. Adjust the DIP-Switch <b>SW3-1</b> .

**NOTE: It will be very helpful to communicate the failure code to the technical assistance service if the service is required.**

## 23 GUARANTEE CONDITIONS

**DOMUSA TEKNIK's commercial guarantee<sup>(\*)</sup>** covers the standard functioning of the products manufactured by **Domusa Calefacción S.Coop.**, in accordance with the following conditions and time periods:

1. This **commercial guarantee<sup>(\*)</sup>** is valid for the following periods, as from the **commissioning date**:
  - 2 Years** for the electric and hydraulic elements: pumps, valves, etc.
  - 5 Years** for the heat pump compressors.
  - 10 Years** for the stainless steel tank unit on FUSION models.
2. **The annual service is not included** in the terms of this guarantee.
3. Sufficient access must be provided for the maintenance and repair of the heat pumps. Costs arising from defective access will not be included in the terms of this guarantee.
4. The **commissioning and annual service** must be carried out by personnel authorised by **DOMUSA TEKNIK**.
5. The **commercial guarantee<sup>(\*)</sup>** will be null and void in the following cases:
  - If the mandatory annual service has not been carried out as specified in the Regulation for Heating Installations in Buildings, by personnel authorised by **DOMUSA TEKNIK**.
  - If the heat pump has not been installed in accordance with the applicable laws and regulations for this type of appliance.
  - If the heat pump has not been commissioned immediately after its installation, by personnel authorised by **DOMUSA TEKNIK**.

Failures due to misuse or incorrect installation, use of non-suitable power or fuel, supply with water with physical or chemical properties causing incrustation or corrosion, incorrect handling of the appliance and, in general, for any reason beyond **DOMUSA TEKNIK's** control, are excluded from this guarantee.

This guarantee does not affect the consumer's rights as stipulated by law.

## NOTES:

[illegible]

## NOTES:

[illegible]

---

# DOMUSA

## T E K N I K

POSTAL ADDRESS  
Section 95  
20730 AZPEITIA  
Tel: +34 943 813 899

FACTORY & OFFICES  
Bº San Esteban, no number  
20737 ERREZIL (Gipuzkoa)  
Fax: +34 943 815 666



CDOC002968 09/11/23

**[www.domusateknik.com](http://www.domusateknik.com)**

**DOMUSA TEKNIK** reserves the right to make modifications of any kind to its product characteristics without prior notice.